



Installation

Kit P/N:

TR-2004P-D
TR-2004B-R

Make:

Lexus

Model:	Year:	Engine:
IS250	06-15	V6-2.5L
IS350	06-15	V6-3.5L

Parts Identification:

- 1 Air filter (Pro Dry S™ TF-9007D)
- 1 Intake tube, 05-T2004P1
- 1 Housing, wrinkle black 05-T2004B2
- 1 Adaptor, 3-angle filter
- 1 Coupling, straight 05-00664
- 1 Coupling, reducer 05-00612
- 2 Clamp #048
- 1 Clamp #072
- 1 Clamp #060
- 1 Trim, rubber edge 1/16" @ 12"L
- 1 Trim, rubber edge 1/16" @ 24"L
- 3 Screws, button head
- 2 Flat washer M6
- 2 Hex screw M6
- 2 Screw M4 x .7 x 8

Tools Required:

- 10mm socket or wrench
- Ratchet w/ extension
- Phillips screw driver
- Flat head screw driver
- 5/16" nut driver
- Pliers
- 4mm allen key

Note: Read instructions before installation and have tools ready.



1



2

Complete Stock intake. Please disconnect battery terminals before installation.



3

Remove engine cover and front/passenger plastic covers.



4

With 10mm socket and ratchet, loosen the two clamps using a 10mm socket or wrench from the OEM intake tube and airbox. Disconnect MAF sensor harness.



5

Remove crank case line from stock intake tube.



6

Carefully remove stock air box assembly out of vehicle.



7

With 10mm socket or wrench loosen the 2 bolts holding in bottom half of air box and remove.



8

Remove MAF sensor using phillips screwdriver.



9

With provided M4 screws, install MAF sensor to new intake tube.



Accessories



Replacement Filter P/N:
TF-9007D



Pre Filter P/N:
TP-7011B

Note: Filter Cleaning: When cleaning your **Pro Dry S™** filter, be sure to use only "Restore Kit" (Takeda P/N: TP-7015C **Pro Dry S™** cleaner only.)

Pro Dry S™ cleaning:
see cleaning instruction sheet TF-9000I.

10



Attach adaptor to housing using button head screws provided. Attach trim seal to top of housing and cut out for scoop.

11



Position housing in the engine compartment.

12



Secure housing using provided screws and flat washers and tighten using 10mm socket or wrench.

13



Install intake tube with couplers and clamps provided. Do not tighten.

14



Re-connect MAF sensor harness and crank case line.

15



Tighten all clamps using 5/16" nut driver.

16



Install air filter and tighten using 5/16" nut driver.

17



Re-install all engine covers.
(Intake is shown with no plastic covers on)

18



The installation of your Takeda performance intake is now complete. Please check all components and re-tighten if necessary. Thank you for choosing Takeda!