



## Installation

**Kit P/N:**  
TR-2006P

**Make:**  
Toyota

**Model:**    **Year:**    **Engine:**  
Corolla    09-14    L4-1.8L

### Parts Identification:

- 1 Air filter ( Pro Dry S™ TF-9002D)
- 1 Intake tube, 05-T2006P1
- 1 Housing, 05-T2006B2
- 1 Coupling, straight 05-00570
- 2 Clamp #044
- 1 7/16" Trim seal @ 16"L
- 2 Flat washer, M6
- 2 Screw hex, M6 x 1 x 16
- 2 Screw M4 x .7 x 8

### Tools Required:

- 10mm socket or wrench
- 13mm socket or wrench
- Ratchet w/ extension
- Phillips screw driver
- Flat head screw driver
- 5/16" nut driver

**Note:** Read instructions before installation and have tools ready.



1



2

Complete Stock intake. Please disconnect battery terminals before installation.



3

Remove engine cover.



4

With 10mm socket or wrench loosen clamp on throttle body. Disconnect MAF sensor harness. Remove crank case line.




5

Remove upper half of air box and stock tube assembly.



6

With 10mm socket or wrench, carefully remove bottom air box assembly out of vehicle. Pull back harness on back of air box.



7

Attach trim seal to housing.



8

Install housing into vehicle and position. Secure housing using provided M6 screws and flat washers. Tighten using 10mm socket or wrench.



9

Remove MAF sensor using phillips screwdriver.





## Accessories



Replacement Filter P/N:  
TF-9002D



Pre Filter P/N:  
TP-7011B

Note: Filter Cleaning: When cleaning your **Pro Dry S™** filter, be sure to use only "Restore Kit" (Takeda P/N: TP-7015C **Pro Dry S™** cleaner only.)

**Pro Dry S™** cleaning:  
see cleaning instruction sheet TF-9000I.

10



With provided M4 screws, install MAF sensor to new intake tube. Attach 05-00570 coupler with clamps to tube.

11



Loosen bolt on side of engine using 13mm socket or wrench.

12



Install intake assembly and position. Do not tighten.

13



Secure tab on tube to engine. Re-install bolt from step 11 and tighten.

14



Re-connect MAF sensor harness.

15



Tighten all clamps using 5/16" nut driver. Connect crank case line to tube.

16



Attach air filter to tube and tighten using 5/16" nut driver.

17



Re-install engine cover. Re-connect battery terminals.

18



The installation of your Takeda performance intake is now complete. Please check all components and re-tighten if necessary. Thank you for choosing Takeda!