



## INSTALLATION INSTRUCTIONS

MAKE: Dodge  
MODEL: RAM 2500/3500  
YEAR: 1994-1998  
ENGINE: L6-5.9L (td) Cummins

**Turbocharger**  
**Wastegate Actuator**  
**(Street) 46-60118**



### Parts Included:

- Actuator, Wastegate
- Clamp Mini
- Washer
- Hose 3/16" ID
- M6 Lockwasher
- M6 Nut
- Bracket
- Spacer, Large
- Spacer, Small
- Bolt, M8 x 50mm
- Bolt, M8 x 30mm

### Qty:

- 1
- 2
- 2
- 7"
- 2
- 2
- 1
- 1
- 3
- 1
- 2

### Tools Needed:

- Pliers
- 10mm Socket
- 13mm Socket
- Ratchet

**CAUTION:** Allow time for your vehicle to cool down prior to installation. When working on your vehicle proceed with caution. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on this product.**

- Step 1:** Remove the bolts, E-clip and hose clamps securing the OE wastegate actuator and bracket to the turbocharger.
- Step 2:** Remove the OE wastegate actuator, bracket and hose from the turbocharger.
- Step 3:** Install the aFe wastegate actuator and bracket on the turbocharger using the supplied hardware. Tighten the mounting bolts and nuts.
- Step 4:** Rotate the threaded rod end link on the actuator shaft until the end link will just engage on the wastegate arm pin. Refer to this as the starting point for the following adjustment.
- Step 5:** Rotate the threaded rod end link clockwise (make the overall rod length shorter) 1 complete rotation. This will set the opening pressure of the wastegate to approximately 40 psi.
- Step 6:** Tighten the jam nut on the threaded rod to prevent rotation during installation.
- Step 7:** Install the supplied hose on the actuator and secure with the supplied hose clamp.
- Step 8:** Direct compressed air (50 psi max) into the opposite end of the supplied hose to activate the actuator.
- Step 9:** Slip the rod end link over the wastegate arm pin.
- Step 10:** Re-install the E-clip removed in **step 1**.
- Step 11:** Connect the hose to the compressor housing and secure with the supplied hose clamp.