



advanced FLOW engineering

Instruction Manual P/N: 77-46406

Make: **Audi** Model: **A4 (B8)** Year: **2009-2016** Engine: **I4-2.0L (t)**

Make: **Audi** Model: **A5 (8T)** Year: **2008-2016** Engine: **I4-2.0L (t)**

Note: **Includes A4 Allroad & Quattro (AWD) models.**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Module	R77-46406
B	1	LED Switch	05-70029
C	2	Hook and loop fastener (2 Inches)	05-01244
D	4	Cable Ties	05-60167

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.



D



C



A



B



SLEEP MODE

Figure A

Refer to Figure A for Step 1.

Step 1: Before installing your aFe module, you will have to place your vehicles ECU in sleep mode. In order to do this you will need to do the following.

- If the engine is cold, open the hood, close the doors, lock the car and wait 30 seconds.
- If the engine is warm, open the hood, close the doors, lock the car and wait 20 minutes.
- If the engine is warm and you can't wait 20 minutes, disconnect the battery

**Figure B****Refer to Figure B for Step 2.**

Step 2: Locate the TMAP ① sensor. The TMAP sensor is on the drivers side behind the headlight and will have a brown connector.

**Figure C****Refer to Figure C for Step 3.**

Step 3: Disconnect the TMAP sensor. Plug the female connector of the aFe POWER harness into the TMAP sensor, then plug the male connector of the aFe POWER harness into the stock female connector.



Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.



Refer to Figures D for Steps 4-5.

Step 4: Carefully route the switch cable behind steering wheel cover.

Step 5: Mount the Switch where desired on an open, flat surface.

**Figure D****Refer to Figure D for Step 6.**

Step 6: Route the switch cable through firewall and into the engine bay. Follow the main harness through the grommet into the firewall. Plug the end of the cable to the module.



Figure E

Refer to Figure E for Step 7.

Step 7: Mount the module in a safe location, using the supplied Hook and loop fastener strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties. Make sure all connections are secured and fully engaged.


Figure F

Refer to Figure F for Step 8.

Step 8: When turning on the vehicle, each LED will flash. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

Thank you for choosing aFe POWER!



OE Replacement Air Filter



P/N: 30-10181 (P5R)
31-10181 (PDS)

Momentum Intake System



P/N: 54-76402 (P5R)
51-76402 (PDS)

Throttle Body Spacer



P/N: 46-39002

Cat-Back Exhaust System



P/N: 49-46403

Sprint Booster V3



P/N: 77-16409