




**CID DESIGN**

# FORD MUSTANG 2015

## INSTALLATION MANUAL

### REAR DIFFUSER MUSTANG 2015

PART # : 1117DNTUFO22A18




**DO NOT WASH CAR** **24 hrs**

**DRIVE SLOWLY 25 mph max**

**READ CAREFULLY BEFORE INSTALLATION**

We recommend 2 persons for installation

### TOOLS




### CHECK LIST

\*Already installed in the part


ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	TIN SCREW 4.8 X 25 MM		2 pcs
<b>D</b>	STAINLESS LOCKNUT M6		4 pcs
<b>E</b>	WASHER M6		8 pcs
<b>F</b>	BUTTON HEAD STAINLESS SCREW M6 X 16		4 pcs
<b>G</b>	BRACKET		2 pcs
<b>H</b>	ADHESIVE POLYURETHANE		1 pc
<b>I</b>	AXIS CLIP		2 pcs
<b>J</b>	SCREW 5/32" X 1/4"		2 pcs
<b>K</b>	PUSH PIN 387		4 pcs
<b>L</b>	ECO DOME		1 pc






**1 REMOVE PUSH PINS**



**If your car have parking sensors,  
drill from the inner side of  
the difuser in the marks with  
a 5/8 metal hole saw drill bit**



**Drill in  
the marks**






CID DESIGN®



# FORD MUSTANG 2015

## INSTALLATION MANUAL


### 2 REMOVE ORIGINAL REFLECTIVE LIGHTS




### 3 PLACE REFLECTIVE LIGHTS ON NEW DIFUSER



### 4 CLEAN




### 5 PRE-MOUNT







**6 MARK**

DRAW CENTER HASH MARK WITH GREASE PENCIL ON REAR DIFFUSER AND SHEET METAL, THIS WILL ENSURE REAR DIFFUSER WILL BE CENTERED TO GREASE PENCIL OUTLINE.




**! HASH MARKS**

**PEEL OFF**



Hold the liner out

**7 PEEL**




**! WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.**




A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.

**8 APPLY ADHESIVE**







**9 PLACE**




**10 PLACE BRACKET (G)**




**11 REMOVE LINER**



**12 PRESS**




**13 PLACE PUSH PINS**







**14** PLACE AXIS CLIP



**15** CLEAN OFF GREASE PENCIL MARK



**INSTALLED PART**






**CID DESIGN**

# FORD MUSTANG 2015

## INSTALLATION MANUAL

### ROCKER WINGLETS MUSTANG 2015




PART # : 1101NXGJFO22A23



**READ CAREFULLY BEFORE  
INSTALLATION**






### TOOLS



### CHECK LIST


\*Already installed in the piece

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	*VHB TAPE		Included in the parts
<b>B</b>	TORX SCREW 3/16" X 3/4"		16 pcs
<b>C</b>	ECO DOME		1 pc




**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**


**1 CLEAN**




**2 ALIGN**



**3 PEEL**




**4 ALIGN & PRESS**




**! A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm² is usually needed and an application temperature between 18 and 40 °C is also necessary. During application, add-on parts and tapes must have the similar temperature.**

**5 DRILL**

**BOTTOM VIEW**



**6 SECURE THE PART**



**! REPEAT ALL 6 STEPS FOR EACH ROCKER WINGLET**






**CID DESIGN®**

# FORD MUSTANG 2015


## INSTALLATION MANUAL

**SIDE SKIRTS MUSTANG 2015**


**PART # : 1118NGJFO22A06**



**READ CAREFULLY BEFORE  
INSTALLATION**







### TOOLS



**T - 20**

### CHECK LIST


*\*Already installed in the part*

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	TORX SCREW 3/16 X 3/4"		4 pcs
<b>B</b>	PUSH PIN WURTH 46		16 pcs
<b>C</b>	WASHER 1/4 "		2 pcs
<b>D</b>	ECO DOME		1 pcs




**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**


**1 REMOVE ORIGINAL**



**2 REMOVE PART**



**3 REMOVE RIVET**






**CID DESIGN**


# FORD MUSTANG 2015

## INSTALLATION MANUAL


### 4 REMOVE ORIGINAL




### 5 CLEAN



### 7 IDENTIFY THE PART



### 8 ALIGN & PLACE





CID DESIGN®


# FORD MUSTANG 2015

## INSTALLATION MANUAL


### 9 PRESS




40-50 N/cm<sup>2</sup>




### 10 ALIGN



### 11 SECURE WITH TORX SCREW





⚠ INNER VIEW



T-20


### 12 REPLACE WHEEL WELL & SECURE WITH TORX SCREW




T-20




**13** PLACE PUSH PINS



**14** RE-INSTALL FRONT WHEEL WELL WITH PUSH PINS



**INSTALLED PARTS**






FORD ACCESSORIES  
Licensed

# FORD - MUSTANG 2015 +

## INSTALLATION MANUAL

### HOOD SCOOP



**WARNING!! Do not install Hood Scoops or other Body Parts directly Over Wrapped areas. Before installation of the parts , you must leave at least a 1/4" (6mm) perimetral clearance "Free from Vinyl" surrounding the part, before Part installation.**




**WARNING!! Do not install Hood Scoops Over Vinyl or Over Plastic Stripes on the Hood: 3M Adhesive Tape and PUR Adhesive must always be in contact with the Sheet Metal of the vehicle.**



**WARNING!! Rust Prevention Oils and other Petrol Based Anti Rust Treatments for Vehicles may affect 3M's Double Adhesive Tape and Polyurethane Adhesive performance!**



**READ CAREFULLY BEFORE  
INSTALLATION**




WE RECOMMEND 2 PERSONS FOR INSTALLATION

**DO NOT  
WASH CAR**




**DRIVE SLOWLY  
25 mph max**



**24 hrs**








**TOOLS**



**CHECK LIST**

**\*Ya instaladas en la pieza**

ITEM	DESCRIPTION	DRAWING	AMOUNT
A	* VHB TAPE		Included in all parts
B	GREASE PENCIL		1 pc
C	POLYURETHANE ADHESIVE		1 pc
D	BLACKOUT		1 pc
E	ECO DOME		1 pc



## INSTALLATION MANUAL

**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**

**! ENSURE VEHICLE SURFACE TEMPERATURE AND PART ARE AT OR ABOVE 60 F / 16 C PRIOR TO INSTALLATION**

### 1 PRE-MOUNT BLACKOUT



**STEPS:**

1. CLEAN SURFACE WITH ACETONE
2. APPLY WATER TO SCOOP AND STICKER
3. PLACE & PRESS


**THIS ELIMINATES GLARE CAUSED BY REFLECTED LIGHT.**




### 2 PLACE BLACKOUT



### 3 CLEAN



### 4 PRE-MOUNT








## INSTALLATION MANUAL


### 5 ALIGN & CENTER



### 6 MARK

#### ! HASH MARKS




WITH THE GREASE PENCIL TIP IN CONTACT WITH THE BODY AND SCOOP, DRAW A DASHED LINE ON THE VEHICLE AROUND THE SCOOP.



### 7 PEEL



ENSURE VEHICLE SURFACE TEMPERATURE AND PART ARE AT OR ABOVE 60 F / 16 C PRIOR TO INSTALLATION



Hold the liner out



A full surface contact between tape and substrate is important for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.




## INSTALLATION MANUAL


### 8 APPLY ADHESIVE



MAKE SURE VEHICLE SURFACE IS COMPLETELY DRY BEFORE INSTALLING




**USE ACETONE TO CLEAN**




**WATER DRAIN**  
KEEP OPEN WITHOUT ADHESIVE

### 9 PLACE



### 10 REMOVE LINER







**11** PRESS

**12** CLEAN OFF GREASE PENCIL MARK


APPLY PRESSURE



40-50 N/cm<sup>2</sup>



**INSTALLED PARTS**






**AIRDESIGN®**

# FORD MUSTANG 2015

## INSTALLATION MANUAL

### FRONT BUMPER MUSTANG 2015


PART # : 1121CXGUFO22A02




Airdesign's Mustang front bumper is designed to align with Fords factory hood, we will not guaranteed alignment of replica hoods.



**READ CAREFULLY BEFORE  
INSTALLATION**



### TOOLS



### CHECK LIST


**\*Already installed in the part**

ITEM	DESCRIPTION	DRAWING	AMOUNT
A	STAINLESS LOCKNUT M6		10 pcs
B	BUTTON HEAD STAINLESS SCREW M6 X 16MM		8 pcs
C	TORX BOLT 3/16 X 3/4"		16 pcs
D	PHILLIPS HEAD SEMS TAPPING SCREW M4 2X20		8 pcs
E	WASHER 1/4"		20 pcs
F	U-NUT 4.2 X 14		12 pcs
G	Z12-BRACKET		4 pcs
H	Z03-BRACKET		8 pcs
I	ALLEN HEAD SCREW M6 X 20MM		2 pcs
J	L - BRACKET		2 pcs
K	TEMPLATE		Included in the manual
L	ECO DOME		1 pcs




### 1 REMOVE FRONT WHEELS


**!** WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE




### 2 REMOVE PUSH PINS FROM RADIATOR COVER



### 3 REMOVE RADIATOR COVER




### 4 REMOVE AND SAVE SCREWS








### 5 REMOVE PUSH PINS





### 6 UNPLUG LIGHTS



### 7 REMOVE SCREW THAT HOLD THE BUMPER TO FENDER




### 8 REMOVE AND SAVE SCREWS







**9 REMOVE FRONT BUMPER**





**10 REMOVE RUBBER SEAL**

**11 REMOVE SCREWS**




**12 REMOVE LIGHTS, GRILLS & IMPACT ABSORBER**







### 13 REMOVE BUMPER RETAINER



### 14 CUT PEAKS





### 15 PLACE BRACKETS (H)










### 16 PLACE BRACKETS (G)




### 17 PLACE TEMPLATE LOCATED ON LAST PAGE & DRILL






**18** PLACE LIGHTS, GRILLS & IMPACT ABSORBER IN NEW FRONT BUMPER




**19** SECURE LIGHTS WITH TORX BOLTS (C)




**21** PLACE RUBBER SEAL

USE SUPER GLUE TO FIX THE RUBBER SEAL  
EDGE TO THE RADIATOR COVER AFTER STEP 25








**20** PLACE NEW FRONT BUMPER












### 22 SECURE THE PART AND PLUG IN THE LIGHTS



### 23 SECURE THE PART




### 24 PLACE L-BRACKET







### 25 PLACE RADIATOR COVER




### 26 PLACE PUSH PINS




### 27 PLACE FRONT WHEELS



### 28 SECURE FRONT WHEELS





## INSTALLED PARTS



# FORD MUSTANG 2015


## DRILL TEMPLATE








## INSTALLATION MANUAL

### QUARTER PANELS SCOOP SET



**DO NOT WASH CAR**  **DRIVE SLOWLY 25 mph max**

**24 hrs**

 **READ CAREFULLY BEFORE INSTALLATION**







 **WE RECOMMEND 2 PERSONS FOR INSTALLATION**

**TOOLS**



### CHECK LIST

\*Already installed in the part


ITEM	DESCRIPTION	DRAWING	AMOUNT
A	* VHB TAPE		Included in all parts
B	GREASE PENCIL		1 pc
C	ADHESION PROMOTER		1 pc
D	ADHESIVE POLYURETHANE		1 pc
E	FOAM CUTS		1 set
F	ECO DOME		1 pc



## INSTALLATION MANUAL


### 1 CLEAN THE SCOOP

**! AFTER PAINTING**




### 2 ADHESION PROMOTER

**! FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE**




### 3 PEEL

**! WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD**




**! A full surface contact between tape and substrate is important for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature at or above 16 °C or 60 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.**

### 4 PLACE GRILL




### 5 REMOVE LINER





## INSTALLATION MANUAL

### 6 PRESS



APPLY PRESSURE





40-50 N/cm<sup>2</sup>

### 7 CLEAN


**!** WASH WITH WATER, DETERGENT AND  
SOFT CLOTH OR SPONGE





### 8 PRE-MOUNT




### 9 ALIGN



### 10 PEEL




### 11 PLACE








12 PRESS




13 CLEAN



! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE



14 PRE-MOUNT




15 ALIGN & CENTER



16 MARK

WITH THE GREASE PENCIL TIP IN CONTACT WITH THE BODY AND SCOOP, DRAW A DASHED LINE ON THE VEHICLE AROUND THE SCOOP.

! HASH MARKS





## INSTALLATION MANUAL

### 17 PEEL





WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD




A full surface contact between tape and substrate is important for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature at or above 16 °C or 60 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.

### PEEL OFF



Hold the liner out






### 18 APPLY ADHESIVE




MAKE SURE VEHICLE SURFACE IS COMPLETELY DRY BEFORE INSTALLING

### 19 PLACE






**20 REMOVE LINER**




**21 PRESS**




40-50 N/cm<sup>2</sup>

**22 CLEAN OFF GREASE PENCIL MARK**




**INSTALLED PARTS**





## INSTALLATION MANUAL

### QUARTER WINDOW SCOOP SET



**WARNING!! Do not install Hood Scoops or other Body Parts directly Over Wrapped areas. Before installation of the parts , you must leave at least a 1/4" (6mm) perimetral clearance "Free from Vinyl" surrounding the part, before Part installation.**



**WARNING!! Do not install Hood Scoops Over Vinyl or Over Plastic Stripes on the Hood: 3M Adhesive Tape and PUR Adhesive must always be in contact with the Sheet Metal of the vehicle.**



**WARNING!! Rust Prevention Oils and other Petrol Based Anti Rust Treatments for Vehicles may affect 3M's Double Adhesive Tape and Polyurethane Adhesive performance!**

DO NOT  
WASH CAR



DRIVE SLOWLY  
25 mph max



24 hrs



READ CAREFULLY BEFORE  
INSTALLATION

G

WE RECOMMEND 2 PERSONS FOR INSTALLATION










**TOOLS**



**CHECK LIST**


\*Already installed in the part

ITEM	DESCRIPTION	DRAWING	AMOUNT
A	* VHB TAPE		Included in all parts
B	GREASE PENCIL		1 pc
C	ADHESION PROMOTER		1 pc
D	BLACKOUT		1 set
E	ECO DOME		1 pc



## INSTALLATION MANUAL


### 1 CLEAN THE SCOOP



### 2 ADHESION PROMOTER





FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE



### 3 PEEL




WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




A full surface contact between tape and substrate is important for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature at or above 16 °C or 60 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.

### 4 PLACE




### 5 REMOVE LINER







**6 PRESS**



**8 APPLY WATER TO WINDOW**




**10 ALIGN**




**7 CLEAN**


**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**



**9 APPLY WATER TO STICKER**




**11 PLACE BLACKOUT**






## INSTALLATION MANUAL

### 12 PRESS



### 13 PRE-MOUNT


**!** MAKE SURE VEHICLE SURFACE IS COMPLETELY DRY BEFORE INSTALLING



### 14 MARK



**!** HASH MARKS

WITH THE TIP OF THE GREASE PENCIL IN CONTACT WITH THE VEHICLE BODY AND THE SCOOP, DRAW A DASHED LINE ON THE VEHICLE AROUND THE SCOOP.



### 15 PEEL

**!** WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




**!** A full surface contact between tape and substrate is important for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.

### 16 ADHESION PROMOTER

**!** FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE



### 17 PLACE








**CID DESIGN**


# FORD - MUSTANG 2015 +

## INSTALLATION MANUAL

### 18 REMOVE LINER



### 19 PRESS




APPLY PRESSURE



40-50 N/cm<sup>2</sup>

### 20 CLEAN OFF GREASE PENCIL MARK



## INSTALLED PARTS

