



CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AMERICAN USA



# FORD - F-150 2015

## INSTALLATION MANUAL

**SPORT FENDER VENTS SET F-150 2015**

**PART # : 1128NZZJFO20A17**




**DO NOT WASH CAR**  **DRIVE SLOWLY 25 mph max**   
**24 hrs**

**! READ CAREFULLY BEFORE INSTALLATION**









**We recommend 2 persons for installation**

**TOOLS**



### CHECK LIST

**\*Already installed in the part**

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	AUTOMOTIVE ADHESION PROMOTER		1 pc
<b>D</b>	TEMPLATE		Included
<b>E</b>	* GRILL		2 pcs
<b>F</b>	* TIN SCREW 5/32" X 3/8"		8 pcs
<b>G</b>	* WASHER 5/32"		8 pcs
<b>H</b>	ECO DOME		1 pc



CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015


## INSTALLATION MANUAL

**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**


### 1 GRILL MOUNT




### 2 REMOVE



### 3 PLACE TEMPLATE



### 4 OUTLINE OUTER CONTOUR WITH MASKING TAPE






CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AMERICAN USA

# FORD - F-150 2015


## INSTALLATION MANUAL

**5** CUT




### CAUTION


PERSONAL  
PROTECTIVE EQUIPMENT  
REQUIRED



**6** FILE DOWN THE EDGE




**7** CLEAN




**8** CORROSION PROTECTION

APPLY ON THE EDGE OF SHEET METAL



**9** PAINT INTERIOR WITH BLACK PAINT





CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015

## INSTALLATION MANUAL


### 10 ALIGN

**!** ALIGN TO THE EDGE OF THE DOOR WITH 1/2" MASKING TAPE.




### 11 MARK

**!** HASH MARKS



**DRAW CENTER HASH MARK WITH GREASE PENCIL ON FENDER VENTS AND SHEET METAL, THIS WILL ENSURE FENDER VENTS WILL BE CENTERED TO GREASE PENCIL OUTLINE.**

### 12 ADHESION PROMOTER





**A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.**

### 13 PEEL



**WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.**

### 14 PLACE






CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA


# FORD - F-150 2015

## INSTALLATION MANUAL

### 15 REMOVE LINER




### 16 PRESS




40-50 N/cm<sup>2</sup>

### 17 CLEAN OFF GREASE PENCIL MARK



## INSTALLED PARTS





**AIRDESIGN**




**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AIRDESIGN USA

# FORD - F-150 2015

## INSTALLATION MANUAL

### FLOOR LINERS SET F-150 2015

PART #: 1140NNTJFO20A13



**ALL TYPE OF CABS**

LH


RH

PART #: 1140ENTUFO20A15

PART #: 1140FNTUFO20A14

### IMPORTANT



**NOT DESIGNED OR RECOMMENDED  
FOR MODELS EQUIPPED WITH VINYL  
FLOORING**



**ONLY SUPER CREW CAB**

PART #: 1140DNTUFO20A16

### TOOLS




**READ CAREFULLY BEFORE  
INSTALLATION**

### CHECK LIST

ITEM	DESCRIPTION	DRAWING	AMOUNT
A	DOME - AIRDESIGN		Included 3 pieces


**1 BEFORE INSTALLING**

MAKE SURE YOUR VEHICLE ALREADY HAVE OEM CAR MAT FASTENERS YOU MUST HAVE THEM FOR PROPER INSTALLATION




IF IT DOES NOT HAVE, GET THIS PARTS FROM YOUR LOCAL DEALER


**2 IDENTIFY**



**3 REMOVE OEM MAT**






**4 VACUM**



**5 MOUNT**


UNOBSTRUCTED



**6 FOR CO-DRIVER'S SIDE REPEAT STEPS 3 & 4**


**RH**

**FRONT**



**BACK**


**8 LIFT UP**



**7 FOR REAR SIDE REPEAT STEPS 3 & 4**

**REAR**


**FRONT**



**BACK**

**9 MOUNT**

**ALIGN**



**IMPORTANT**

**FAILURE TO CORRECTLY INSTALL OR RE-INSTALL THE FLOOR LINER TO THE ABOVE INSTUCTIONS COULD RESULT IN THE LOSS OF CONTROL OF THE VEHICLE AND DEATH OR SERIOUS INJURY.**

**REGULAR CLEANIGN EXTENDS THE LIFE OF YOUR FLOOR LINERS. CLEAN USING ONLY A MILD DETERGENT SOAP AND WATER. DO NOT USE HARSH CHEMICALS OR ABRASIVE TYPE CLEANERS AS THESE PRODUCTS MAY DAMAGE THE FLOOR LINER.**



CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AMERICAN USA

# FORD - F-150 2015

## INSTALLATION MANUAL

### DOOR ROCKER PANEL SET F-150 2015


PART # : 1124NJFO20D03



**DO NOT  
WASH CAR**



**DRIVE SLOWLY  
25 mph max**



**24 hrs**




**READ CAREFULLY BEFORE  
INSTALLATION**



**We recommend 2 persons for installation**







## TOOLS



## CHECK LIST

\*Already installed in the part

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	ADHESION PROMOTER		1 pc
<b>D</b>	ECO DOME		1 pc





CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015


## INSTALLATION MANUAL

### FRONT & REAR ROCKER PANEL

**!** WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE

#### 1 CLEAN



FACTORY DOOR MOLDING HAVE TO BE REMOVED BEFORE INSTALLING DOOR ROCKER PANEL



#### 2 PRE-MOUNT

FRONT

REAR



Keep the indicated separation between the panels and the edge of the doors as shown in the picture.




CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015

## INSTALLATION MANUAL


### 3 MARK HASH MARKS




**DRAW CENTER HASH MARK WITH GREASE PENCIL ON PANELS AND SHEET METAL, THIS WILL ENSURE PANELS WILL BE CENTERED TO GREASE PENCIL OUTLINE.**

### 4 ADHESION PROMOTER


**FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE**




### 5 PEEL WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




### 6 PLACE



 **A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.**

### 7 REMOVE LINER






CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

**FORD - F-150 2015**


**INSTALLATION MANUAL**

**8** PRESS




40-50 N/cm<sup>2</sup>

**9** CLEAN OFF GREASE PENCIL MARK



**INSTALLED PARTS**





CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015


## INSTALLATION MANUAL

### SUPER-BOLT FENDER FLARES SET F-150 2015

PART # : 1109NNTJFO20A08




READ CAREFULLY BEFORE  
INSTALLATION



DO NOT  
WASH CAR




DRIVE SLOWLY  
25 mph max





24 hrs

### TOOLS



6mm



3 mm



10mm  
6mm  
7mm  
9/32

### CHECK LIST

\*Already installed in the part

ITEM	DESCRIPTION	DRAWING	AMOUNT
A	* SUPER BOLTS' RUBBER STUDS		16 pcs
B	* STAINLESS SUPER BOLT M6 X14		34 pcs
C	* STAINLESS LOCKNUT M6		18 pcs
D	HEX BOLT M4.2 X 20		22 pcs
E	AUTOMOTIVE ADHESION PROMOTER TESA # 60153		1 pc
F	APPLICATION SPONGE		1 pc
G	GREASE PENCIL		1 pc
H	PVC PROFILE		29 ft
I	PUSH PINS WURTH 46		4 pcs
J	S-CLIP		6 pcs
K	U-CLIP		6 pcs
L	U-NUT		8 pcs
M	THREADLOCKER 222		1 pc
N	ECO DOME		1 pc


F-150 MODELS THAT ARE EQUIPPED WITH THE 68T TECHNOLOGY PACKAGE, WILL REQUIRE AN ADAPTATION FOR THE LANE DEPARTURE SENSOR ON THE FRONT WHEEL FLARES. THIS SENSOR IS LOCATED NEAR THE LOWER ROCKER AREA OF THE FRONT FENDER.

**FRONT RIGHT & LEFT FLARE**


**WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**

**INNER VIEW**

**1 REMOVE MUD GUARDS**




**2 REMOVE SCREWS**




**3 CLEAN**




**4 PRE-MOUNT**



**5 SECURE THE PART**




**6 MARK SILHOUETTE & SUPER BOLTS POSITION**




**HASH MARKS**

**DRAW CENTER HASH MARK WITH GREASE PENCIL AT CENTER, BOTH SIDES, ON EACH SUPER BOLT AND SHEET METAL. THIS WILL ENSURE WHEEL FLARE WILL BE CENTERED TO GREASE PENCIL OUTLINE.**


**7 UNSCREW & REMOVE**




**8 REMOVE**




**9 CLEAN** **! FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ALCOHOL**




**10 ADHESION PROMOTER**




**11 REMOVE LINER**




**12 PLACE**



**13 SECURE THE PART**




**14** APPLY PRESSURE ON EACH SUPERBOLT




**15** REMOVE SUPER BOLTS (B)


**!** ONLY THE ONES WITH RUBBER STUD



**16** UNSCREW & REMOVE





**17** REMOVE



**SUPER BOLT INSTALLATION**


**18** PRESS SUPER BOLTS' STUDS (A)



**ATTENTION**

FOR GOOD ADHESION IT IS NECESSARY TO APPLY AS MUCH PRESSURE AS POSSIBLE ALL OVER THE EDGE AND CENTER OF THE SUPER BOLTS STUDS.

**SUPER BOLT STUDS**



**!** **PRESSURE POINTS**




40-50 N/cm<sup>2</sup>




A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.


**19 PLACE PVC TRIM**



**20 REMOVE LINER**




**21 PLACE SUPER BOLTS STUDS (A)**




**ATTENTION**  
**22 APPLY LOCTITE THREADLOCKER TO SUPER BOLT'S THREAD**




**23 PLACE SUPER BOLTS (B)**




**24 SECURE THE PART**




**25 PLACE S-CLIPS (I)**









**25** CLEAN OFF GREASE PENCIL MARK




**REAR RIGHT & LEFT FLARE**


**1** REMOVE PUSH-PINS




**2** PLACE U-NUTS (K)




**3** PRE-MOUNT




**4** SECURE THE PART




**5** ALIGN INTERIOR & MARK




**6 MEASURE & MARK**




**7 REMOVE**



**8 DRILL**




**9 PLACE U-NUTS (K)**




**10 CLEAN**




**11 PRE-MOUNT**



**12 SECURE THE PART**




**13 MARK**




**HASH MARKS**

**DRAW CENTER HASH MARK WITH GREASE PENCIL AT CENTER, BOTH SIDES, ON EACH SUPER BOLT AND SHEET METAL. THIS WILL ENSURE WHEEL FLARE WILL BE CENTERED TO GREASE PENCIL OUTLINE.**

**14 UNSCREW**




**15 REMOVE**




**16 CLEAN**

**!** FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ALCOHOL




**17 ADHESION PROMOTER**

APPLICATION AREA



**18 REMOVE LINER**

**!** WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




**19 PRE-MOUNT**


**!** ALIGN WHEEL FLARE TOP EDGE WITH THE GREASE PENCIL HASH MARKS AND PLACE.

**20 SECURE THE PART**


We recommend 2 persons for installation




**21 APPLY PRESSURE ON EACH SUPER BOLT**



**22 UNSCREW**





**23 REMOVE**  **ONLY THE ONES WITH RUBBER STUD**



**SUPER BOLT INSTALLATION**


**24 PRESS SUPER BOLTS' STUDS (A)**



**ATTENTION**

FOR GOOD ADHESION IT IS NECESSARY TO APPLY AS MUCH PRESSURE AS POSSIBLE ALL OVER THE EDGE AND CENTER OF THE SUPER BOLTS STUDS.

**SUPER BOLT STUDS**



**! PRESSURE POINTS**





40-50 N/cm<sup>2</sup>




A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.


**25 PLACE PVC TRIM (G)**




**26 PLACE PVC TRIM**



**27 PLACE SUPER BOLTS STUDS (A)**



**28 SECURE THE PART**




**! ATTENTION**


**29 APPLY LOCTITE THREADLOCKER TO SUPER BOLT'S THREAD**



**30 PLACE SUPER BOLTS (B)**



**31 PLACE U-CLIPS (J)**






CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA


# FORD - F-150 2015

## INSTALLATION MANUAL

### 32 DRILL




### 33 PLACE PUSH PINS (H)



### 34 CLEAN OFF GREASE PENCIL MARK



## INSTALLED PARTS





CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AMERICAN USA

# FORD - F-150 2015

## INSTALLATION MANUAL

### TAILGATE APPLIQUE F-150 2015


PART # : 1140NNTUFO20A032



**DO NOT  
WASH CAR**



**DRIVE SLOWLY  
25 mph max**



**24 hrs**



**READ CAREFULLY BEFORE  
INSTALLATION**

**We recommend 2 persons for installation**



## TOOLS



**1/4"**



## CHECK LIST

**\*Already installed in the part**

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	ADHESION PROMOTER		1 pc
<b>D</b>	ECO DOME		1 pc



CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015


## INSTALLATION MANUAL

### 1 CLEAN

**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**



### 2 PRE-MOUNT




### 3 MARK

**! HASH MARKS**


### ALIGN & CENTER

ALIGN TOP WITH 1/4" MASKING TAPE



### 4 ADHESION PROMOTER

**! FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE**



**DRAW CENTER HASH MARK WITH GREASE PENCIL ON EACH APPLIQUE AND SHEET METAL, THIS WILL ENSURE APPLIQUE WILL BE CENTERED TO GREASE PENCIL OUTLINE.**

**! A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.**






CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015

## INSTALLATION MANUAL


**5 PEEL** WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




**PEEL OFF**  
Hold the liner out




**7 REMOVE LINER**



**9 CLEAN OFF GREASE PENCIL MARK**




**6 PLACE**




**8 PRESS**

**APPLY PRESSURE**



40-50 N/cm<sup>2</sup>

**INSTALLED PART**





CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY AMERICAN USA


# FORD - F-150 2015


## INSTALLATION MANUAL

### TAILGATE WING SPOILER F-150 2015


PART # : 1102DNTUFO20A033



**DO NOT WASH CAR**  **24 hrs**

**DRIVE SLOWLY**  
25 mph max 

**READ CAREFULLY BEFORE INSTALLATION**





We recommend 2 persons for installation 

### TOOLS



### CHECK LIST

\*Already installed in the part

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	ADHESION PROMOTER		1 pc
<b>D</b>	ECO DOME		1 pc



CID DESIGN


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015

## INSTALLATION MANUAL


### 1 CLEAN

**!** WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE




### IMPORTANT

ENSURE THE SURFACES ARE COMPLETELY CLEAN BEFORE INSTALLING



### 2 PRE-MOUNT




### 3 MARK




**HASH MARKS**



**ALIGN & CENTER**



GREASE PENCIL





**DRAW CENTER HASH MARK WITH GREASE PENCIL ON SPOILER AND SHEET METAL, THIS WILL ENSURE SPOILER WILL BE CENTERED TO GREASE PENCIL OUTLINE.**

### 4 ADHESION PROMOTER



**FIRST CLEAN ALL OVER THE APPLICATION AREA WITH ACETONE**



**A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.**



CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

# FORD - F-150 2015



## INSTALLATION MANUAL

**5** PEEL




WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.

**PEEL OFF** Hold the liner out




**7** REMOVE LINER



**9** CLEAN OFF GREASE PENCIL MARK



**6** PLACE




**8** PRESS

APPLY PRESSURE



40-50 N/cm<sup>2</sup>

### INSTALLED PART





**CID DESIGN**


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY KIMBERLIN USA

# FORD - F-150 2015

## INSTALLATION MANUAL

**HOOD SCOOP F-150 2015**

**PART # : 1129CPNUFO20A01**




**DO NOT WASH CAR**

**DRIVE SLOWLY**  
25 mph max

**24 hrs**



**READ CAREFULLY BEFORE INSTALLATION**



We recommend 2 persons for installation

**WARNING!!** Do not install Hood Scoops or other Body Parts directly Over Wrapped areas. Before installation of the parts , you must leave at least a 1/4" (6mm) perimetral clearance "Free from Vinyl" surrounding the part, before Part installation.

**WARNING!!** Do not install Hood Scoops Over Vinyl or Over Plastic Stripes on the Hood: 3M Adhesive Tape and PUR Adhesive must always be in contact with the Sheet Metal of the vehicle.

**WARNING!!** Rust Prevention Oils and other Petrol Based Anti Rust Treatments for Vehicles may affect 3M's Double Adhesive Tape and Polyurethane Adhesive performance!



**CID DESIGN**


**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY INNOVATION USA

**FORD - F-150 2015**

**INSTALLATION MANUAL**








## TOOLS



## CHECK LIST

\*Already installed in the part

ITEM	DESCRIPTION	DRAWING	AMOUNT
<b>A</b>	* VHB TAPE		Included in the parts
<b>B</b>	GREASE PENCIL		1 pc
<b>C</b>	POLYURETHANE ADHESIVE		1 pc
<b>D</b>	BLACKOUT		1 pc
<b>E</b>	ECO DOME		1 pc



CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY KIMBERLY USA

# FORD - F-150 2015

## INSTALLATION MANUAL


**! WASH WITH WATER, DETERGENT AND SOFT CLOTH OR SPONGE**

### 1 PRE-MOUNT BLACKOUT


STEPS:

- 1. CLEAN SURFACE WITH ACETONE
- 2. APPLY WATER TO SCOOP AND STICKER
- 3. PLACE & PRESS


**THIS ELIMINATE GLARE CAUSED BY REFLECTED LIGHT.**




### 2 PLACE BLACKOUT





### 3 CLEAN



### 4 PRE-MOUNT




### 5 ALIGN & CENTER



### 6 MARK ! HASH MARKS

**DRAW CENTER HASH MARK WITH GREASE PENCIL ON HOOD SCOOP AND SHEET METAL, THIS WILL ENSURE HOOD SCOOP WILL BE CENTERED TO GREASE PENCIL OUTLINE.**





CID DESIGN

**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY HUNTERDUN USA



# FORD - F-150 2015

## INSTALLATION MANUAL

### 7 PEEL




WARM SURFACES WITH HEAT GUN IF SURFACE TEMPERATURE IS TOO COLD.




A full surface contact between tape and substrate is decisive for good adhesion performance. Contact is achieved by applying pressure. In practice a pressure between 40 and 50 N/cm<sup>2</sup> is usually needed and an application temperature between 25 and 45 °C or 77 and 113 °F is also necessary. During application, add-on parts and tapes must have the similar temperature.

### 8 APPLY ADHESIVE




USE ACETONE TO CLEAN



**WATER DRAIN**  
KEEP OPEN WITHOUT ADHESIVE

Keep the indicated separation 1"







CID DESIGN



**SUPER RIM**  
TRUCK ACCESSORIES POWERED BY KIMBERLY USA

**FORD - F-150 2015**

**INSTALLATION MANUAL**



**9 PLACE**  USE ACETONE TO CLEAN

**10 REMOVE LINER**



**11 PRESS**

**12 CLEAN OFF GREASE PENCIL MARK**



40-50 N/cm<sup>2</sup>

**INSTALLED PARTS**

