



## Installation Instructions

For Part Numbers:

200-133 700-433 Airaid Oiled Media Filter  
 201-133 701-433 SynthaMax Dry Media Filter - Red  
 202-133 702-433 SynthaMax Dry Media Filter - Black

1996-05 Chevrolet S10 Blazer  
 1996-04 Chevrolet S10/GMC Sonoma  
 1996-01 GMC Jimmy  
 1991-01 Oldsmobile Bravada  
 4.3L V6



INTAKE SYSTEMS FOR VEHICLES LISTED ARE 50 STATE LEGAL. SEE CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

### Component Identification

1.	Airaid Premium Filter	1
2.	Black MAF Panel	1
3.	Black Side Panel	1
4.	Weather Strip 32 <sup>3</sup> / <sub>4</sub> "	1
5.	M6-1x25 Hex Bolt	4
6.	1/4" Flat Washer	4
7.	6/32 Screw	3
8.	6/32 Keps Nut	3
9.	#6 Flat Washer	3
10.	Airaid Decal	1

#### 1) DISCONNECT NEGATIVE (-) BATTERY CABLE.

#### 2) Remove the Factory Air Filter Housing.

- A) Unscrew & remove the four wing nuts from the air cleaner housing lid.
- B) Loosen the rubber clamp to the mass air flow meter and remove air filter lid from vehicle. Do not remove mass air sensor. **See Fig#1**
- C) Remove the factory air filter from the air filter base. **See Fig#1** (*Note: Retain the air filter housing base. The Airaid Quick Fit intake system will mount on top of the factory base.*)
- D) Using a T-25 torx bit screwdriver (star head), remove three of the four bolts from the factory mass air sensor. **See Fig#2**  
 Retain bolts for later use. (**Important: The lower left bolt must remain in the mass air sensor**)

#### 3) Airaid Intake System Assembly & Installation

- A) Assemble the Quick Fit panels with the three nuts and bolts supplied. **Refer to Fig#3**
- B) Position the Quick Fit panel assembly on top of the factory air filter base. (*Note: The factory mass air sensor slides into the cool air box.*)
- C) Mount the mass air sensor on the Quick Fit panel using the three factory torx bolts removed previously.
- D) Using the supplied bolts and washers, mount the Quick Fit panel on the factory air filter base.
- E) Install the Airaid premium filter on the end of the mass air sensor. Tighten hose clamp using a flat blade screwdriver. **Refer to Fig#3**
- F) Install the supplied weather striping onto top of Quick Fit panel. **Refer to Fig#3** (*Note: Weather striping has been pre cut for proper fit.*)


#### 4) Finishing Up...Apply the Airaid Foil Decal onto the Panel as shown below.

- A) Check for any foreign objects or debris in the intake path.
- B) Check for proper hood clearance.

**Fig#1**

**Fig#2**

**Fig#3**



**WARNING!** If your vehicle has a Vehicle Emission Control Information decal affixed to the factory airbox, a new replacement label must be obtained and installed in a readily visible position in the engine compartment in order to remain CARB compliant. Failure to do so will prevent the vehicle from passing a smog check. Replacement labels can be ordered from your local dealership. Regulations state that the VECI label shall not be affixed to any equipment which is easily detached from the vehicle. Label placement, under the hood on a painted surface is recommended.

Thank you for purchasing the Airaid Intake System. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned periodically.

## FILTER IDENTIFICATION

700-433 Airaid Oiled Media

701-433 Airaid SynthaMax Dry Media - Red

702-433 Airaid SynthaMax Dry Media - Black

**For your Oiled media filter  
we suggest using the AIRAID  
Filter Tune-Up Kit!**

**SynthaMax<sup>®</sup>**

**Do Not Oil**



P/N 790-551 Aerosol Spray  
P/N 790-550 Squeeze Spray

Synthamax Air Filters do not require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green<sup>®</sup>, Formula 409<sup>®</sup> or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water or air to clean filter. Allow filter to air dry and reinstall.

