

Classic Update Series

1967-75 Mopar A-Body

START HERE !

PLEASE READ THIS BEFORE STARTING INSTALLATION !

This wiring kit is designed for ease of installation. Please read, BEFORE STARTING your installation, to guarantee a successful job. Use an appropriate crimping tool, which folds the wings of the open barrel terminals down into the wire, as shown on this page. If you use our crimping tools and correctly crimp the included terminals, soldering is not necessary. If you are unsure about a particular crimp, soldering is recommended. Our factory crimped terminations are installed by GM approved five ton presses, and soldering these terminations is not necessary.

AS THIS HARNESS IS DESIGNED FOR USE IN A MODIFIED CAR, REQUIRING A HIGHER RATE OF CHARGE, IT DOES NOT SUPPORT THE USE OF A STOCK (ORIGINAL) ALTERNATOR. IT IS DESIGNED FOR USE WITH A SINGLE WIRE STYLE INTERNALLY REGULATED ALTERNATOR.

STEP 1: DISCONNECT YOUR BATTERY:

Disconnect the battery before installing the wiring kit to prevent any accidental shorting caused by loose bare wire ends.

STEP 2: START INSTALLING KIT:

This kit is broken down into individual steps that are identified by a letter printed on the instruction sheets visible through each bag. These letters are the order of operation for installing your kit. Start with bag letter **G**, then **H**, etc. The order of installation is shown below.

- G - 510604 Dash Harness Kit
- H - 510605 Gauge Cluster Kit
- J - 510606 Engine Kit
- L - 510607 Front Light Kit
- M - 510608 Rear Body Kit

STEP 3: RECONNECT YOUR BATTERY:


When you have completed the installation and are ready to reconnect the battery, make sure that the following electrical system grounds are in place:

- A. Battery is grounded to the ENGINE BLOCK.
- B. Battery is grounded to the frame.
- C. Engine block is grounded to the frame.
- D. Body is grounded to the frame.

STEP 4: CHECK ALL ELECTRICAL FUNCTIONS:

Any non-functioning items should be checked for proper installation. Any problems with your wiring and electrical circuit functions should be addressed to American Autowire Systems, Inc. as soon as possible to avoid any warranty problems.

The terminals that we supply in our kits, utilize what is known as an F crimp. The F crimp, in a cross section, will look like the illustration below, when done correctly.



We carry many accessories for your 1967-75 MOPAR A-BODY

p/n 510585
OEM small terminal crimping
tool (18-14 gauge)



p/n 510586
OEM large terminal crimping
tool (12-8 gauge)



p/n 500100
Door Jamb Switch,
self-tapping
(fits a 3/8"-24 hole)



p/n 500235
Billet Aluminum
Knob
(fits a 1/4" shaft)



p/n 500236
Billet Aluminum
Knob
(fits a 3/16" shaft)



PART #

510603

DESCRIPTION:

1967-75 Mopar A-body
Classic Update Series Kit

92971187

AMERICAN AUTOWIRE MAKES IT EASY !!

American Autowire provides the best automotive electrical parts.