

Installation Instructions for IB08DCE6

by APS Auto Parts Specialist Inc.

Application: For 2017-2018 Honda CR-V
Estimated Time: 1 to 2 hours



Disclaimer: Instructions intended for persons aged 18+ please do not attempt without adult supervision. Instructions are not intended to replace professional installation. Damage from improper installation, misuse or modification to the product voids the manufacturer's warranty.

PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#01	2	Running Board(use for left or right)	#8	18	M8 x 1.25 -25mm Hex Bolts
#02	1	Driver Front Mounting Bracket(DFM)	#9	18	8mm x 24mm OD x 2mm Flat Washers
#03	1	Passenger Front Mounting Bracket(PFM)	#10	18	M8 Lock Washers
#04	1	Driver Center Mounting Bracket(DCM)	#11	12	M6 x 1.0- 20mm "T" Bolts
#05	1	Passenger Center Mounting Bracket(PCM)	#12	12	M6 Flat Washers
#06	1	Driver Rear Mounting Bracket(DRM)	#13	12	M6 Nylon Lock Nuts
#07	1	Passenger Rear Mounting Bracket(PRM)	#14		



PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ FACTORY BODY BOLT REMOVAL INSTRUCTIONS AND INSTALLATION INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

1. Identify and separate the driver and passenger side Mounting Brackets. Start installation on the Driver /Left side of the vehicle. Remove the plastic cover under the driver side of the vehicle, **(Figure 1)**.
2. Select the Driver /Left Front Mounting Bracket. Attach the outer end of the Driver /Left Front Mounting Bracket to the (2) threaded holes next to the pinch weld with the included (2) M8 Hex Bolts, (2) M8 Lock Washers, and (2) M8 Flat Washers, **(Figure 2a)** Attach the inner tab on the bracket to the threaded hole in the bottom of the inner frame channel with the included (1) M8 Hex Bolt, (1) M8 Lock Washer, and (1) M8 Flat Washer, **(Figure 2a)**. Leave hardware loose at this time. **IMPORTANT:** The Front and Center Mounting Brackets are similar but they are not same, **(Figure 2b)**.
3. Move to the center of the vehicle and repeat **Steps 1-2** for Center Mounting Bracket installation, **(Figure 3)**. **NOTE:** There is the dry glue on the driver side of the vehicle and block one mounting hole on the center brackets. Please carefully scrap off the glue before install the driver side center mounting bracket, **(Figure 4)**.
4. Continue along the side of the vehicle to the rear mounting location. Select the Driver /Left rear Mounting Bracket. Attach the bracket to the vehicle with (3) M8 Hex Bolts, (3) M8 Lock Washers, and (3) M8 Flat Washers. Do not tighten all hardware at this time. **(Figure 5)**


5. Select a Running Board. Slip (6)M6 T-bolts into each bottom channel (**Figure 6**). Carefully position the Running Board onto the (3) Mounting Brackets. **IMPORTANT:** Do not slide, (front to back), the Running Board on the Brackets or damage to the finish may result. Attach the Running Board to each Mounting Brackets with (2) M6 T-bolts, (2)M6 flat washers and (2)M6 Nylon Lock Nuts (**Figures 7**). Do not tighten at this time.
6. Level and adjust Running Board properly and tighten all hardware. **NOTE: Torque all M6 nylon lock nuts to 7 lb-ft.**
7. Once all hardware has been completely tightened, reinstall the plastic cover with the factory hardware.
8. Repeat **Steps 2—7** for passenger/right Running Board installation.
9. Do periodic inspections to the installation to make sure that all hardware is secure and tight

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.


For Polished Finishes: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

For Black Finishes: Mild soap may be used to clean the Running Board.


Driver Side Installation Pictured Without Plastic Cover for Instruction Purposes Only



(Fig 1) Driver /Left Mounting Location Pictured




(Fig 2a) Driver /Left Front Mounting Bracket Pictured




(Fig 2b) Driver /Left Front Mounting Bracket Pictured


Driver Side Installation Pictured Without Plastic Cover for Instruction Purposes Only




(Fig 3) Driver /Left Center Mounting Bracket Pictured



(Fig 4) Driver Side Center Mounting Position Pictured



(Fig 5) Driver /Left Rear Mounting Bracket Pictured



- (2)M6T-bolts
- (2)M6 Flat Washers
- (2)M6 Nylon Lock Nuts

