

These instructions are intended for the following part numbers:
2660-15046



AWE S-FLO SHORTIE CARBON INTAKE FOR TTRS AND RS3 INSTALLATION GUIDE:

Vehicle Fitment:

- 2017-2019 Audi RS3 Sedan 2.5L Turbo
- 2017-2019 Audi TTRS Coupe 2.5L Turbo

Thank you for purchasing the **AWE 4.5" S-FLO Shortie Carbon Intake** for TTRS and RS3.

Exquisite build quality with industry leading performance distinguish this intake kit from all others.

PARTS LIST



INSPECT ALL PARTS PRIOR TO DISASSEMBLY OF VEHICLE; IF DAMAGED OR MISSING, PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.

AWE 4.5" S-FLO Shortie Carbon Intake

Arrow	QTY	Description	Part Number
A	1	2.5T carbon filter tube	500031
B	1	4.5in cone filter	400002
C	1	Filter mounting plate	120028
D	1	AWE to OE turbo tube coupler	300006
	1	100-120 worm drive clamp	5574K25
	1	110-130 worm drive clamp	5574K26
	3	Carbon tube bolts	94500A231
	3	Oversized flat washer	91116A150



PARTS LIST



INSPECT ALL PARTS PRIOR TO DISASSEMBLY OF VEHICLE; IF DAMAGED OR MISSING, PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.

AWE DV Adapter Kit for 2019+ Models

Letter	QTY	Description	Part Number
A	1	2019+ 2.5T DV adaptor	150006
B	1	Oil-resistant soft buna-n O-rings, 1/16 fractional width	2418T121
C	1	Oil-resistant soft buna-n O-rings, 3/32 fractional width	2418T145
D	2	Worm-drive clamps, 5/16" band width, 24-38mm clamp ID	5388K24
F	1	1" ID black high temp reinforced silicone heater hose - 8.75"	HTHH-100-BLK






NOTE: Always refer to the manufacturer's service manual for precise torque specifications on all OEM fasteners.



CAUTION: The engine may be **VERY HOT** — allow adequate time for the system to cool down before disassembly. Severe burns and injury will occur if skin comes into contact with a hot engine.

STEP 1

Begin by removing the engine cover by carefully pulling it upward, as seen in **Figure 1-1** and **1-2**.





STEP 2

Remove the OEM inlet duct, by removing the 2 screws pointed out in **Figure 2-1**, then carefully push it towards the engine and remove it from the vehicle, shown in **Figure 2-2**.



STEP 3


Loosen the 2 hose clamps holding the OEM intake hose in place, shown in **Figure 3-1**, then carefully remove the intake hose from the intake, shown in **Figure 3-2**.



STEP 4

Pre-2018 model only.

Remove the hose from the OEM intake, pointed out in **Figure 4-1**. To remove, squeeze the clamp tabs together and wiggle the hose off, shown in **Figure 4-2**.





STEP 5

2019+ model only.

Remove the 2 bolts on the engine side of the OEM diverter valve hose, shown in **Figure 5-1**. This will allow the diverter valve hose to be removed with the OEM intake, shown in **Figure 5-2**.



Note: These 2 bolts will be reused in the install of your AWE diverter valve.



STEP 6

Remove the OEM air intake box, shown in **Figure 6-1**, by first detaching the sensor at the front of the air box, then pulling it upwards detaching it from the OEM rubber mounting grommets below the air box, shown in **Figure 6-2**.

Note: These 3 rubber grommets, these will be reused with the AWE intake system.



STEP 7

2019+ model only.


Gather the AWE diverter valve adapter and the 2 O-rings provided, and install these onto the diverter valve, as shown in **Figure 7-1** and **7-2**.



STEP 8


2019+ model only.

With the O-rings installed onto the adapter, install it into the OEM location, and reinstall the 2 OEM bolts removed earlier, shown in **Figure 8**.



STEP 9

Gather the AWE mounting bracket and push in the 3 OEM rubber mounting grommets, as shown in **Figure 9**.



STEP 10

Secure the AWE carbon intake tube onto the AWE mounting bracket, with the 3 supplied screws and oversized washers, as shown in **Figure 10**.



Careful to not over tighten bolts, carbon could crack.




FIGURE 10

STEP 11

Install the AWE air filter onto the AWE intake tube and tighten the hose clamp, as shown in **Figure 11**.




FIGURE 11

STEP 12

Install the AWE carbon fiber intake filter section into the vehicle, by pushing the OEM rubber mounting grommets into place and aligning the silicone flex tube, as shown in **Figure 12-1** and **12-2**.




FIGURE 12-1





FIGURE 12-2

STEP 13


Align the silicone flex hose and tighten the 2 hose clamps, as shown in **Figure 13**.



STEP 14


For **Pre-2018**, reinstall the hose and clamp removed earlier, as shown in **Figure 14-1**.

For **2019+**, install the provided hose and hose clamps, shown in **Figure 14-2**.



STEP 15

Clip the OEM sensor onto the AWE mounting plate shown in **Figure 15**.




STEP 16

Reinstall the OEM inlet duct, with the hardware removed earlier, as shown in **Figure 16**.



STEP 17

Reinstall the OEM engine cover by pressing it back into place, as shown in **Figure 17**.



ENJOY!



TROUBLESHOOTING

Issue	Solution
Wrong or missing parts	Double check the parts list for your system and compare them with what you received. Fill out our contact form, found below and let us know what parts you need.
Check engine light	Make sure all hoses are reinstalled and are all secure.

CARE

This is a re-usable air filter that can be cleaned when dirty and put back into service. Please inspect the air filter element every 25,000 miles for integrity. Clean every 50,000 miles under normal operating conditions, sooner in dusty conditions. Contact AWE to purchase a filter maintenance kit.