



HDCC-01 Honda clock retention 2012-2014

FEATURES

- Provides accessory power (12-volt 10-amp)
- Used in amplified and non-amplified systems
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- ASWC-1 harness included (ASWC-1 sold separately)
- High level speaker input
- Retains balance and fade
- Retains ability to change the factory clock
- Retains factory 3.5 AUX jack
- Micro "B" USB updatable

INTERFACE COMPONENTS

- HDCC-01 interface • HDCC-01 harness
 - 8-pin subwoofer harness
 - 16-pin harness with stripped leads

APPLICATIONS

HONDA

Civic	2012-2013
CR-V	2012-2014

TOOLS REQUIRED

- Cutting tool • Tape • Crimping tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

***Note:** Refer also to the instructions included with the aftermarket radio.

Connections to be made

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the (2) **Red** wires to the accessory wire.
- Connect the **Orange/White** wire to the illumination wire. If the aftermarket radio does not have an illumination wire, tape it off and disregard it.
- Tape off and disregard the **Gray, Gray/Black, Green, Green/Black, and Brown** wires, they will not be used in this application.

The following wires are for the aftermarket radios that have navigation built in:

- Connect the **Light Green** wire to the parking brake wire (if applicable).
- Connect the **Blue/Pink** wire to the VSS or speed sense wire (if applicable).
- Connect the **Green/Purple** wire to the reverse wire (if applicable).

From the HDCC-01 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Blue/White** wire to amp turn-on wire.
- Connect the **White/Red** RCA to the audio AUX in of the aftermarket radio (if equipped).

(continued on next page)

For the following (8) wires, if the vehicle does not have a factory amplifier, cut off the RCA jacks to expose the speaker wires and use those instead.

- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative speaker output.

From the 8-pin subwoofer harness to the aftermarket radio (amplified models only):

- Connect the **White** RCA to the subwoofer output.

12-pin pre-wired ASWC-1 harness:

This harness is to be used along with the optional ASWC-1 (not included) to retain steering wheel audio controls. If the ASWC-1 is not being used, disregard this harness. If it will be used, please refer to the ASWC-1 instructions for radio connections and programming.

Note: *Disregard the harness that comes with the ASWC-1.*

Installing the HDCC-01

With the key in the off position:

- Connect the 16-pin harness with stripped leads into the interface.
- Connect the HDCC-01 harness into the interface, and then into the vehicle.
- With all connections completed, reconnect the negative battery terminal.

Note: *If using the ASWC-1, connect it after you initialize and test the HDCC-01, with the key in the off position.*

Initializing the HDCC-01

Attention: *If the HDCC-01 loses power for any reason, the following step will need to be performed again.*

- Initialize the interface by turning the ignition on for 30 seconds, then turn the ignition back off, then back on again.

Extra features

Setting the factory clock:

- Press and hold the SOURCE button on the steering wheel for 15 seconds to get into the clock setting mode.
- Press SEEK-UP or SEEK-DOWN to select hours, minutes, etc. Press VOLUME-UP or VOLUME-DOWN to set the values.
- Either press SOURCE again, or wait 5 seconds with no activity to exit the clock setting mode.