



Installation instructions for part LC-GMRC-LAN-03

LC-GMRC-LAN-03 GM data bus interface 2006-2012

INTERFACE FEATURES

- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (retained accessory power)
- Provides NAV outputs (parking brake, reverse, and speed sense)
- Used in non-amplified models, or when bypassing a factory amplifier
- Used in models without OnStar
- Retains all warning chimes
- High level speaker input
- Retains balance and fade
- Micro "B" USB updatable

APPLICATIONS

CHEVROLET	PONTIAC	SATURN
Cobalt 2007-2010	G5 2007-2009	Aura 2007-2009
HHR 2006-2011	G6 2010	Sky 2007-2009
Malibu 2008-2012	G6 (5th digit of VIN must be a J, K, or L) 2009	
	Solstice 2006-2009	

Note: This interface will not retain OnStar.

Table of Contents

Connections to be made.....	2
Installing the Axxess Interface	3
Initializing the Axxess Interface	3

INTERFACE COMPONENTS

- LC-GMRC-LAN-03 interface
- LC-GMRC-LAN-03 harness

TOOLS REQUIRED

- Wire cutter • Crimping tool • Tape • Solder gun
- Connectors (butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.





LC-GMRC-LAN-03

Connections to be made

From the LC-GMRC-LAN-03 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- Connect the **Blue** wire to the power antenna wire.
- If the aftermarket radio has an illumination wire, connect the **Orange/White** wire to it.
- Tape off and disregard the (2) Orange wires, they will not be used in this application
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative speaker output.

The following (3) wires are only for multimedia/navigation radios that require these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.



LC-GMRC-LAN-03

Installing the Axxess interface

With the key in the off position:

- Connect the LC-GMRC-LAN-03 harness into the interface, and then to the wiring harness in the vehicle.

Initializing the Axxess interface

Attention: *If the Axxess interface loses power for any reason, the following steps will need to be performed again.*

- Turn the key (or push-to-start button) to the ignition position and wait until the radio comes on.

Note: *If the radio does not come on within 60 seconds, turn the key to the off position, disconnect the interface, check all connections, reconnect the interface, and then try again.*

- Turn the key to the off position, and then to the accessory position.
- Test all functions of the installation for proper operation, before reassembling the dash.

Our installation parts and kits make aftermarket stereo and video installation a breeze.