

Part#: **124501** 

Product: 5-6" Front Track Bar Relocation Bracket

Application: 1987-1995 Jeep YJ

## READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

**SAFETY WARNING** BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

## INSTALLATION INSTRUCTIONS

- 1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
- Disconnect the front track bar from the passenger's side of the axle. Loosen the track bar-to-frame bolt to allow the track bar to slide in the slotted frame bracket hole.
- 3. Temporarily attach the new track bar bracket to the axle with the 12mm x 60mm bolt, nut and 7/16" USS washers provided (BP #907). The offset in the plate will go up and the tab with a slotted hole will fit in between the casting webs.
- 4. Mark the location of the slotted hole using the bracket as a template.
- 5. Remove the bracket and drill a 7/16" hole and the mark through the track bar axle mount. Note: It may be necessary to disconnect the steering stabilizer from the axle to allow for drill clearance.
- 6. Reattach the new bracket to the axle with the 12mm hardware. Also, attach the bracket through the newly drilled hole with a 7/16" x 1-1/4" bolt, nut and 7/16" SAE washer (BP #907). Torque 7/16" hardware to 50 ft-lbs and 12mm hardware to 70 ft-lbs.
- 7. Install the track bar to the front face of the new bracket with the provided 12mm x 70mm bolt, nut and 7/16" USS flat washers (BP #907). Torque hardware to 70 ft-lbs.
- 8. Torque the track bar-to-frame mount bolt to 70 ft-lbs.
- 9. Check all hardware for proper torque.
- 10. Check hardware after 500 miles.



