



Part#: **553001**

Product: **Front Dual Shock Kit**

Application: **Ford Super Duty**

BDS Suspension are proud to offer a high quality product at the industries most competitive pricing!

## **READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

---

**SAFETY WARNING** BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

**PRODUCT SAFETY WARNING** Certain BDS Suspension products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. BDS Suspension Co. does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

### **PRE-INSTALLATION NOTES**

1. Special literature required: OE Service Manual for model/year of vehicle. Refer to manual for proper disassembly/ reassembly procedures of OE and related components.
2. Adhere to recommendations when replacement fasteners, retainers and keepers are called out in the OE manual.
3. Larger rim and tire combinations may increase leverage on suspension, steering, and related components. When selecting combinations larger than OE, consider the additional stress you could be inducing on the OE and related components.
4. Post suspension system vehicles may experience drive line vibrations. Angles may require tuning, slider on shaft may require replacement, shafts may need to be lengthened or trued, and U-joints may need to be replaced.
5. Secure and properly block vehicle prior to installation of BDS Suspension components. Always wear safety glasses when using power tools.
6. If installation is to be performed without a hoist, BDS Suspension Co. recommends rear alterations first.
7. Due to payload options and initial ride height variances, the amount of lift is a base figure. Final ride height dimensions may vary in accordance to original vehicle attitude. Always measure the attitude prior to beginning installation.

### **POST-INSTALLATION WARNINGS**


1. Check all fasteners for proper torque. Check to ensure for adequate clearance between all rotating, mobile, fixed, and heated members. Verify clearance between exhaust and brake lines, fuel lines, fuel tank, floor boards and wiring harness. Check steering gear for clearance. Test and inspect brake system.
2. Perform steering sweep to ensure front brake hoses have adequate slack and do not contact any rotating, mobile or heated members. Inspect rear brake hoses at full extension for adequate slack. Failure to perform hose check/ replacement may result in component failure. Longer replacement hoses, if needed can be purchased from a local parts supplier.
3. Perform head light check and adjustment.
4. Re-torque all fasteners after 500 miles. Always inspect fasteners and components during routine servicing.

## PARTS LIST

Part #	Qty	Description
01018	2	Dual Shock Bracket
408	1	Bolt Pack
	4	1/2" x 6-1/2" bolt
	4	1/2" lock nut
	8	1/2" flat washer
31	2	1.00" x 0.219" x 1.50" spacer sleeve
54314	8	0.625" x 0.060" x 1.475" sleeve



## INSTALLATION INSTRUCTIONS

1. Block the rear wheels for safety.
  2. Raise and support the front axle with jack stands.
  3. Remove the front tires and wheels.
  4. Remove the OE shocks.
  5. Remove the three bolts retaining the upper shock mount to the frame on both sides of the vehicle.
  6. Drill out both lower factory shock mount holes to 1/2".
  7. Install the supplied 1" OD x 1-1/2" long sleeve in between the factory lower shock mount tabs.
  8. Install the supplied upper shock mounting brackets into the existing factory holes with the factory hardware and torque to 65 ft-lbs.
  9. Install the supplied sleeves in the shock eyes.
  10. Attach the shock cylinders to each side of the new upper mount using the supplied 1/2" bolt and torque to 65 ft-lbs.  
Note: It may be necessary to trim the inner fender shroud to provide clearance for the shocks.
-  *Note: When installing the fox 2.0 shocks, it may be necessary to invert (upside-down) the cylinders. This will increase clearance with the lower factory mount.*
11. Attach the lower eye of the shocks to each side on the lower OE mount with the supplied 1/2" bolts and torque to 65 ft-lbs.
  12. Install the wheels and tires.
  13. Lower the vehicle to the ground.
  14. Check all fasteners after 100 miles.