




Rear Upper Control Arm Bushing BK017

Required Tools:

- Hydraulic jack and 2 stands (lift optional but recommended)
- Wrenches – 18mm, 21mm
- Sockets – 10mm, 13mm, 18mm, 21mm
- Pry-bar

Installation:

1. Lift vehicle and support with stands under the rocker jack points as shown in **Image 1** below.
2. Remove both rear wheels.
3. Using a 15mm socket, remove the driveshaft tunnel brace. See **Image 2**.



4. Using a 15mm socket, loosen the exhaust clamps at the front of the exhaust.
5. Using a helper, slide the rear muffler mounts off the mounting dowels (**Image 3**) and then pull the entire exhaust assembly rearward and out of the car.




Continued

Rear Upper Control Arm Bushing BK017 (Continued)



6. Using a 10mm socket, remove the front driveshaft tunnel exhaust shield. See **Image 4**. This will prevent the driveshaft from damaging the shield when lowering the rear cradle.
7. Un-plug the fuel pump wiring harness located on the passenger side of the car next to the front cradle bushing. See **Image 5**.
8. Support the cradle with a hydraulic jack or adjustable frame stands.
9. Twist the emergency brake cable while pulling up to “release” it from the bracket attached to the upper control arm on each side. **Image 6**.



Rear Upper Control Arm Bushing BK017 (Continued)

10. Using a 21mm socket, remove the 4 cradle mounting bolts. See **Image 7** on the previous page. Lower the cradle approximately 2-3 inches.

11. Using a 21mm wrench and 21mm socket, remove the inner front bolt on the upper control arm. See **Image 8** to the right.



12. Using an 18mm wrench and 18mm socket, remove the outer bolt on the upper control arm. **Image 9** above.

13. Remove the two 18mm bolts at the rear of the upper control arm.

14. Remove the upper control arm.

15. Note the orientation of the rear bushing saddle on the control arm before removing the bushing. Using a 21mm socket, remove the bushing retainer bolt as shown in **Image 10** above.

16. Using a hydraulic press, remove the OE bushing from the saddle.

17. Position the bushing shell to match the original orientation then push the BMR bushing into the shell with the flange of the bushing towards the outside of the A-arm. Insert the provided sleeve then attach the assembly to the upper control arm. Place the provided washer over the bolt then tighten the bolt to 130 ft/lbs. Re-install control arm using the OE mounting hardware. Torque the rear saddle bolts to 85 ft/lbs. Torque the front inner mount to 130 ft/lbs. Torque the outer bolt to 85 ft/lbs.

Rear Upper Control Arm Bushing BK017 (Continued)

12. Lift the cradle up against the frame making sure that the rear alignment dowels are seated properly then insert the 4 mounting bolts. Torque all bolts to 130 ft/lbs.
13. Re-install the emergency brake cable to the bracket.
14. Plug the fuel pump wiring harness back in.
15. Bolt the driveshaft back into place and torque the three bolts to 85 ft/lbs.
16. Re-install the driveshaft tunnel exhaust shield.
17. Re-install the exhaust.
18. Bolt the driveshaft tunnel brace back into place and torque to 45 ft/lbs.
19. Install the rear wheels and lower the vehicle.