



## TCA034 - LOWER CONTROL ARM INSTALLATION

Lower control arms, DOM, non-adjustable, poly bushings

*NOTE: When performing this installation it is recommended to do one side at a time. Removing both lower control arms at the same time allows the rearend to move making re-installation more difficult.*

### **Installation:**

1. Lift vehicle and support with jack stands under the frame rails.
2. If equipped, remove all 4 sway bar bolts and remove the sway bar.
3. Remove both bolts from one control arm and remove the arm.
4. Clean the bushing mounting surfaces in the frame. If you purchased control arms equipped with polyurethane bushings, lube the outside of the bushings using a silicone based polyurethane lube.
5. Install the new control arm but do not tighten the bolts. Repeat steps 3-5 for the other side. If you are using control arms equipped with spherical bearings you may proceed to step 7.
6. Once both new control arms are installed and bolts are finger tight, load the rear suspension by placing the jack stands under the axle. It is necessary when using polyurethane bushings to properly load the bushings before tightening the mounting bolts. *NOTE: tightening the control arm bolts with the rear end hanging results in bushing preload and can cause irregular ride height and premature bushing wear.*
7. Tighten bolts to 80 ft/lbs.
8. Re-install the sway bar.
9. Using a grease gun with a silicone based polyurethane lube, lube each grease fitting with 1-2 pumps. For maximum longevity, re-grease at 500 miles and then every other oil change.
10. Lower vehicle.