



NON-ADJUSTABLE TOE RODS

TR002 – 2010-present Camaro

RECOMMENDED TOOLS:

Hydraulic Jack and stands

Wrenches: 10mm, 22mm

Sockets: 18mm, 22mm

INSTALLATION:


1. Lift vehicle and support with stands under the frame rails.
2. Remove the rear wheels/tires.
3. Pop the ABS wire loose from the OE toe rod by squeezing the retaining clips from the backside. (**Image 1**)



4. The inner bolt of the toe rod controls alignment and must be marked before loosening in order to maintain proper alignment settings during re-assembly. Using a paint marker or chalk, mark the cam washer and subframe as shown in **Image 2**.
5. Due to fuel tank interference, the drivers' side inner toe rod bolt cannot be removed without lowering the cradle. Support the cradle as shown in **Image 2b** below. Using a 15/16" socket, remove the front two cradle bolts and loosen the rear bolts. The cradle should lower enough to remove the bolts.



6. Using a 22mm wrench and 22mm socket, remove the inner bolt.
7. Using an 18mm socket remove the outer bolt and then remove the toe rod.
8. Install the BMR Toe Rod using the OE bolts. The ABS mounting tab should be on top and grease fittings pointing down.
9. Re-install the front cradle bolts and tighten all four to 130 ft/lbs.



NON-ADJUSTABLE TOE RODS (Cont.)

TR002 – 2010-present Camaro

10. Using a 10mm wrench rotate the inner bolt until the cam washer lines up with the mark made previously. Tighten to 85 ft/lbs. Tighten the outer bolt to 95 ft/lbs. (**Image 3** on the following page)
11. Snap the ABS clips into the tabs on top of the BMR Toe Rod.
12. Grease each bushing with a silicone based grease.
13. Re-install the wheels/tires. Lower vehicle.



BMR Toe Rod and Trailing Arm