

INSTALLATION INSTRUCTIONS



FIG 1




FIG 2

1. Disconnect the vehicle's negative battery cable.
2. Locate the vehicle's power distribution box and the trailer tow relay block attached to it, located in the engine compartment on the driver's side. Open the cover(s) to access the relays and fuses.
3. Consulting your owner's manual, locate the Trailer Tow Electric Brake and Trailer Tow Battery Charge fuse locations and insert the 30 amp maxi-fuses (provided) into them.
4. Consulting your owner's manual, locate the Trailer Tow Backup Lamp Relay and the Trailer Tow Battery Charge Relay locations and insert the relays (provided) into the trailer tow relay block.
5. Close the Power Distribution box cover(s).
6. Locate the vehicle's wiring harness plugs located in the rear, underneath the vehicle, near the driver's side frame rail behind the bumper. The plug should match the trailer wiring harness end.
7. Disconnect the vehicle's 4-flat plug or remove the cap and install the trailer tow harness into the mating plug (Fig 2).
8. Reconnect the vehicle's negative battery cable.
9. Plug the 7-way socket (provided) into the trailer tow harness.
10. Test the installation with a test light or trailer.
11. Secure all loose wires and mount the trailer tow harness in an accessible location with a bracket or electrical box (not included).

Note: The existing 4-flat harness on the Vehicle will not be functional. Depending on your vehicle's build date and trim level you may not use all Fuses and/or Relays provided.