





Installation instructions



(Full Size Dodge Van without Factory 7-Way)

1. Locate the tow vehicle's trailer harness connector **A**. This harness is located under the vehicle, behind the bumper, on the driver's side of the vehicle (Fig 1).
2. Remove protective cap **B** (and save) from connector **A**; check to see that the mating surfaces of the connectors are free or dirt. Clean if necessary (Fig 1).
3. Connect the T-connector adapter end **C** to the vehicle's connector **A**. Be sure that the T-connector is fully inserted with locking tabs in place.
4. Place protective cap **B** on on remaining plug end (Fig 1). Skip to step 7 for remaining installation instructions.

(Durango, Dakota, Full Size Ram, Jeep Grand Cherokee & Dodge Van Equipped with a Factory 7-way trailer tow package) (Fig. 2)

5. Remove the screws on the bracket that hold the 7-way in place (Fig. 2). Pull out 7-way to access plug on the back of the 7-way. Slide the red tab to the unlocked position, and separate the connector **A** (Fig. 3).
6. Connect the T-Connector adapter in between the separated halves **B**. Slide the red locking tab to the locked position (Fig 3). Route the 4-flat connector away from the 7-way bracket. Push the 7-way back into the bracket and reinstall the screws **C**.
7. Test the installation with a test light or trailer.

This unit is rated for 7.5 amps per circuit.

REESE