



Installation Instructions T-Connector



READ THIS FIRST:
Read and follow all instructions carefully before beginning installation.



1. Remove the rear interior trim panels that are near the doors. Locate the vehicle's taillight wiring harness **A**. The taillight wiring harness will have a connection point, on both sides, matching the ends of the T-Connector.
2. Disconnect the vehicle wiring harness connectors on the driver's side, being careful not to damage the locking tabs.



3. Plug the T-Connector end with the **yellow** wire in-between the mating plugs on the Driver's side taillight socket and vehicle wiring harness. Ensure that the connectors are fully inserted together utilizing existing and supplied locking tabs.
4. Locate a suitable grounding point near the connector such as the vehicle's frame or cross member. (Do not drill into vehicle floor or bed.) Clean dirt and rustproofing from area. Drill a 3/32" hole and secure **white** wire using eyelet and screw provided.

⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

5. Repeat steps 2 & 3 on passenger's side with T-connector end containing the **green** wire.

⚠ WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

6. Tuck the **green** wire under the floor trim (threshold) panel. Replace the vehicle's rear trim panels.

⚠ WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: 1 per side (7.5 amps)
- Max. tail lights: (7.5 amps)

Read vehicle's owners manual and instruction sheet for additional information.