


Installation Instructions


T-Connector



A



E




B

C



F



D



Tools Recommended:

Drill (3/32" Drill Bit), Philips Head Screwdriver, Trim Panel Remover

1. Locate the vehicle wiring inside the vehicle's rear cargo area by removing both of the wiring access side panels **A B C**. Carefully remove the foam insulation padding on each side to access the taillight connection points **D**. There will be connection points matching the ends of the T-Connector adapter behind each of the vehicle taillight housings **D**.

NOTE

There are two sets of taillight connection points. Use the top set of connection points for the T-Connector.

2. Beginning on the driver's side, separate the vehicle's wiring connectors, being careful not to break the locking tabs. All connector surfaces should be clean and free of dirt. Attach each end of the T-Connector containing the **yellow** wire. Ensure that the connectors are fully inserted with locking tabs in place.
3. Pull up the cargo floor panel, and remove the cargo tray by unscrewing the spare tire hold down nut. Pull out cargo tray and set aside. Route the T-Connector containing the **green** wire behind and under the trim panel, along the vehicle floor near the spare tire **F**. Continuing, route wire across the vehicle and behind the trim panel and up to the wiring access area. Repeat step 2 for the passenger's side using the T-Connector containing the **green** wire.

4. Locate a suitable grounding point near the connector. (Do not drill into vehicle floor or bed.) Clean dirt and rustproofing from area. Drill a 3/32" hole and secure **white** wire using eyelet and screw provided.

⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

⚠ WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

5. Secure the remainder of the T-Connector harness with the cable ties provided, to prevent damage or rattling and being careful to avoid any areas that would pinch, cut or melt the wire.
6. Replace both foam insulation padding, wiring access panels, cargo tray, spare tire hold down nut, & cargo floor panel removed during installation.

NOTE

Store 4-Flat connector in rear cargo area when not in use.

🔥 ⚠ WARNING

Overloading circuit can cause fires.

DO NOT exceed lower of vehicle manufacturer rating or:

- Max. stop/turn light: 7.5 amps per side
- Max. tail lights: 7.5 amps

Read vehicle's owners manual & instruction sheet for additional information.