





# Installation Instructions

## T-Connector



# HIDDEN HITCH



### TOOLS REQUIRED:

Drill (3/32" Drill Bit), Philips Head Screwdriver

1. Locate the black plastic protective covers on each side of the vehicle, under the vehicle next to the bumper **A**. Remove the two plastic trim fasteners on each side, securing the protective covers, to access vehicle's wiring harness. Locate the vehicle's wiring harness behind the protective cover. There will be connection points matching the ends of the T-Connector adapter.

#### NOTE

On some vehicles, the vehicle wiring harness is located behind the protective cover and above the rear bumper bracket **B C**.

2. Beginning on the driver's side, remove the foam tape attached to the plugs and separate the vehicle's wiring harness connectors, being careful not to break the locking tabs **D E**. Ensure that the mating surfaces are free of dirt. Clean if necessary.
3. On the driver's side, insert the T-Connector end, with the **yellow** wire, between the vehicle wiring connectors and lock into place. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place.
4. Repeat steps 2 & 3 on passenger's side with T-Connector end containing the **green** wire.

5. Locate a suitable grounding point near the adapter such as the vehicle frame or crossmember. (Do not drill into vehicle floor or bed.) Clean dirt and rustproofing from area. Drill a 3/32" hole and secure **white** wire using eyelet and screw provided.

#### ⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

#### ⚠ WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

6. Bundle and secure wires to the vehicle's crossmember using the cable ties provided. Route the 4-Flat to the center of the vehicle's crossmember using cable ties provided. Re-install protective covers removed in step 1.

#### NOTE

Mount 4-Flat in a suitable location under the vehicle. Bracket not included.



#### ⚠ WARNING

Overloading circuit can cause fires.

DO NOT exceed lower of vehicle manufacturer rating or:

- Max. stop/turn light: (7.5 amps)
- Max. tail lights: (7.5 amps)

Read vehicle's owners manual & instruction sheet for additional information.