



## Installation Instructions

### T-Connector



#### TOOLS REQUIRED:

Trim Panel Remover, 10mm Socket & Ratchet or 10mm Wrench, Drill (3/32" Drill Bit), 1/4" socket

1. Open the rear door of the vehicle and temporarily remove the rear threshold, cargo net and cargo cover to allow access of the rear interior trim panel on the driver's side **A**.

#### NOTE

It may be helpful to fold rear seat forward.

2. Using a trim panel remover tool carefully pull back the interior trim panel on Driver's side **B**.
3. Locate the vehicle's white trailer tow plug, located behind the trim panel removed in step 2 **C**.
4. Check to see that the mating surfaces of the vehicle wiring connectors match the T-Connector ends. All connector surfaces should be clean and free of dirt.
5. Insert the T-Connector harness into the vehicle's Tow-Plug harness and lock into place **D**.

6. On the driver's side, locate a suitable grounding point near the connector such as an existing ground stud or drill a 3/32" hole and secure the **white** wire using the eyelet and screw provided. (Do not drill into vehicle floor or bed.) Clean dirt and rustproofing from area.

#### ⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

#### ⚠ WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

7. Reinstall the threshold, trim panel, cargo net and cover.
8. Store 4-Flat connector in rear cargo area when not in use.



#### ⚠ WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: 1 per side (2.1 amps)
- Max. tail lights: (5 amps)

Read vehicle's owners manual & instruction sheet for additional information.