



Installation Instructions

T-Connector



Honda Crosstour



ENGLISH

TOOLS REQUIRED:

Trim Panel Remover, 10mm Socket & Ratchet or 10mm Wrench, Drill (3/32" Drill Bit), 1/4" Socket, Wire Crimpers, Wire Cutters, Philips Head Screwdriver, Test-probe

1. Open rear hatch. Temporarily remove all floor coverings & center storage bin **A**.
2. Locate the passenger side cargo tray bolt by carefully prying open the dust cover **B**. Remove the bolt and being carefull not to break the clips that hold the cargo tray pull up and remove passenger side cargo tray.
3. Remove cargo loop **C**, being careful not to damage clips, partially remove the lower interior trim panel on passenger side of the vehicle.
4. Locate the white tow plug at the rear of the vehicle under the drivers side trim panel. It has black tape holding it to the wire harness. Insert the T-Connector harness into the vehicle's Tow-Plug harness and lock into place
5. On passengers side, locate a flat surface in a out of the way place and mount the T-Connector's black convertor box with the double sided tape.
6. Route the 4-Flat through the passengers side trim panel into side storage compartment and store there when not in use.
7. Open Hood and locate fuse box on drivers side **D**. Open fuse box and insert 15 amp fuse provided into empty location shown **E**.
8. All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.
9. Reinstall the plastic trim panels, threshold, storage covers, floor covering and other items that may have been removed during installation, being careful not to pinch or cut the wires.

WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: 1 per side (2.1 amps)
- Max. tail lights: (5.6 amps)

Read vehicle's owners manual & instruction sheet for additional information.