



Manufacturers and distributors  
of quality chassis, suspension, driveline  
and components

# Drive Shaft Loop Kits

Part#: C/E 4034,4035,4036,4037,4038

## C/E 4034 Drive Shaft Loop Kit w/Sleeves and pins

- 1...Cut the drive shaft loop to the correct height. Slide the mounting sleeves half way into the drive shaft loop.
- 2...With the mounting sleeves only half way into the loop, hold the drive shaft loop in the correct position and tack weld the mounting sleeves to the crossmember. (Within 6" of the front U-Joint). Check that the loop is centered over the drive shaft.
- 3...Weld the mounting sleeves completely. Slide the drive shaft loop over the mounting sleeves.
- 4...Drill a 5/16" hole through the bottom of each side of the drive shaft loop for the mounting pins.

## C/E4035 Drive Shaft Loop Kit with Crossmember

- 1...Mount the crossmember between the frame rails within 6" of the front U-Joint.
- 2...Cut the drive shaft loop to the correct height. Slide the mounting sleeves half way into the drive shaft loop.
- 3...With the mounting sleeves only half way into the loop, hold the drive shaft loop in the correct position and tack weld the mounting sleeves to the crossmember. (Within 6" of the front U-Joint). Check that the loop is centered over the drive shaft.
- 4...Weld the mounting sleeves completely. Slide the drive shaft loop over the mounting sleeves.
- 5...Drill a 5/16" hole through the bottom of each side of the drive shaft loop for the mounting pins.

## C/E Drive Shaft Loop Only

This loop can be installed in any type of car to retain the drive shaft in case of failure.

## C/E4036 Drive Shaft Loop Kit with Crossmember 360°

- 1...Mount the crossmember between the frame rails within 6" of the front U-Joint.
- 2...Cut the drive shaft loop to the correct height. Slide the mounting sleeves half way into the drive shaft loop.
- 3...With the mounting sleeves only half way into the loop, hold the drive shaft loop in