

Please take time to read and understand these installation instructions.

CORSA recommends that the installation of this system be performed by a qualified service center or professional installer who has the necessary equipment, tools and experienced personnel. However, if you decide to perform this install, the use of the recommended tools below will be required.

CAUTION: Never work on a hot vehicle. Allow time for the vehicle to cool before attempting an install.

Recommended Tools:

- 8mm socket/nut driver
- T20 Torx screwdriver
- 2.5 mm Allen wrench

Please confirm that all parts are present before beginning the factory intake system removal and CORSA intake system installation.

Bill of Materials:

- A. 1 – Main carbon fiber inlet section
- B. 1 – High flow air filter
- C. 1 – Silicone coupler
- D. 2 – Band clamps
- E. 1 – Rubber grommet
- F. 1 – Mass Air Flow (MAF) sealing gasket
- G. 2 – M4 Allen head screws
- H. 2 – Rubber Backed sealing washers



Factory (OEM) Intake System Removal

1. Using an 8mm socket/nut driver loosen the band clamps between the OEM intake and the throttle body. (See Fig. A)
2. By hand remove the small breather hose that plugs into the side of the inlet next to the throttle body. This is done by pulling and no tools are required. (See Fig. B)
3. By hand remove the grey locking tab and wire that plugs into the side of the Mass Air Flow (MAF) sensor. This is done by depressing the tab on the top of the sensor and by pulling apart. No tools or excessive force are required on this step. If the connector does not want to come apart the tab is likely not being depressed correctly. (See Fig. C)
4. Intake is held in place by two rubber grommets, these will be removed and **reused** during installation.
5. With Steps 1-4 completed, Remove the complete OEM intake system (including rubber coupler) by lifting it out of the car. (See Fig. D)

This completes the removal of the factory intake system.



Fig. A



Fig. B



Fig. C



Fig. D

Installation of CORSA Intake System:

1. On the OEM intake system there are two rubber grommets that attach the system to the radiator cover. Transfer these grommets from the OEM system to the small round holes on the bottom of the carbon fiber inlet. **(See Fig. E)**
2. Install the supplied grommet in the carbon fiber inlet near the MAF sensor.
3. Using a Torx T-20 screwdriver remove the two screws that attach the MAF sensor to the OEM inlet body. With the screws removed, pull the sensor out of the OEM inlet. **Observe the MAF sensor's proper orientation to the throttle body by noting the arrow's direction. (See Fig. F)**
4. At the base of the MAF sensor there is a thin rectangular shaped rubber gasket that should be discarded.
5. Locate the supplied foam gasket. Remove the white paper backing. Affix the foam gasket to the MAF sensor resting against its base. (Do **NOT** the side the wires plug into).
6. Install the MAF sensor to the carbon inlet using the supplied M4 Allen head screws and rubber backed sealing washers. Ensure that the head of the screws contact the **METAL SIDE** of the washers and that the sensor is **NOT INSTALLED BACKWARDS!** **(See Fig. G)**
7. Unwrap the included high flow air filter and fit the carbon fiber inlet into the neck of the filter. Ensure that the carbon fiber inlet is well seated into the filter. Tighten the large band clamp. **(See Fig. H)**
8. Slide the included silicone coupler over the carbon fiber inlet. Slide the two included band clamps over the silicone coupler.
9. Lower the complete inlet assembly into position ensuring that the two grommets installed in Step 1 are seated and that the silicone hose connects between the throttle body and the carbon fiber inlet. At this stage tighten the two band clamps fixing the silicone coupler in place. **(See Fig. I & J)**
10. Re-connect the MAF wire. Reinsert the breather hose into the supplied grommet.
11. Start the vehicle and check for any loose connections. Allow the car to idle for at least 5 minutes before driving.

INSTALLATION PICTURES ON NEXT PAGE 

CORSA Installation Pictures



Fig. E



Fig. F



Fig. G



Fig. H



Fig. I



Fig. J