


# I-2042


## BUICK ENCLAVE GMC ACADIA SATURN OUTLOOK

ELECTRIC BRAKE CONTROL  
ADAPTER HARNESS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



HARNESS HOUSING

VEHICLE HOUSING

### WIRE COLOR DESIGNATORS DESIGNADORES DEL COLOR DEL ALAMBRE INDICATEURS DE COULEUR DE FIL

BLACK	>	BATTERY POWER (+)
NEGRO	>	ENERGÍA DE BATERÍA (+)
NOIR	>	PUISSANCE DE BATTERIE (+)
WHITE	>	GROUND (-)
BLANCO	>	TIERRA (-)
BLANC	>	LA TERRE (-)
RED	>	BRAKE SIGNAL FROM VEHICLE
ROJO	>	SEÑAL DEL FRENO DEL VEHÍCULO
ROUGE	>	SIGNAL DE FREIN DE VÉHICULE
BLUE	>	ELECTRIC BRAKE FEED TO TRAILER
AZUL	>	ALIMENTACIÓN ELÉCTRICA DEL FRENO AL ACOPLADO
BLEU	>	ALIMENTATION ÉLECTRIQUE DE FREIN AU BAS DE PAGE



# CURT™

The **FIRST** Name  
in Towing Products™

## English

1. Carefully remove vehicle trim panel underneath dash making sure not to pull on courtesy lamp wires that are attached.
2. Locate the vehicle's electric brake control harness connector. The harness will be located underneath the dash and left of the steering column, taped to another harness near the emergency brake pedal. There will be a 6-pin connector that mates with the one on the adapter.
3. Plug the brake control adapter into the vehicle electric controller connector. Use butt connectors and attach the wires from the adapter to the corresponding wires on the electric brake control, following the brake control manufacturer's installation instructions.
4. Complete the installation per the electric brake control manufacturer's instructions and mount the unit as directed. Perform test procedures as instructed.

### NOTE

Vehicles not equipped with OEM trailer tow package, may require fuses and relays to complete output and battery feed circuits (sold separately). Consult owners manual for locations.