

# 56044

CADILLAC CTS






## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Open the trunk and remove the vehicles rear scuff panel. [A][B] On the passenger side remove the battery compartment cover to reveal the vehicles wiring harness. [C] Repeat on the drivers side removing the felt trunk liner. [D]

2. On the passengers side separate the vehicles taillight harness by using a flathead screwdriver to depress the locking tab. [E][F] Place full assembly in battery compartment. Insert the T-Connector end with the green wire in-between the separated housings making sure the locking tabs are in place.

3. Route the T-Connector end with the yellow wire under the felt trunk liner and under the vehicles removed rear scuff panel, under the felt trunk liner on the drivers side. Repeat step 2 on the drivers side using the T-Connector end with the yellow wire.

4. On the passengers side disconnect the vehicles positive battery cable. Attach the the terminal ring to the vehicles positive battery post and reconnect the positive battery cable. Insert the fuse provided into the fuse holder.

5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

6. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

7. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in the battery compartment.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.