


13028 / RRH1302888-91 CHEVY/GMC 4 DR CREW CAB ONLY
73-06 CHEVY/GMC FULL SIZE CAB & CHASSIS w 34" FRAME
62-87 CHEVY/GMC ALL FULL SIZE: except 10" bumper73-79 FORD 250 CREW CAB
73-06 FORD PICKUP: CAB AND CHASSIS 34" frame widthGROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 6,000 LBS. TRAILER WEIGHT & 600 LBS. TONGUE WEIGHT.
GROSS LOAD CAPACITY WHEN USED AS A WEIGHT DISTRIBUTION HITCH: 10,000 LBS. TRAILER WEIGHT & 1,000 LBS. TONGUE WEIGHT*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	6	1/2 - 13 x 2"	CARRIAGE BOLT
2	6	HFN 1213	HEX FLANGE NUT
3	12	CM-SP1	.250 x 1.50 x 2.00" SQUARE HOLE SPACER



HITCH WEIGHT: 36 LBS.
 INSTALL TIME: 45 MINUTES
 INSTALL NOTES:
 -REMOVE SPARE TIRE
 -DRILLING REQUIRED
 -RE-INSTALL SPARE TIRE

INSTALLATION STEPS

- 1) Remove spare tire and rear bolt on tire holder. Clean mounting surface as needed.
- 2) Place spacers between hitch and frame as shown (clamp hitch into position). Using the hitch as a template, mark and drill 1/2" mounting holes. Make sure wires and hoses will not be damaged when drilling.

NOTE: hitch must be positioned so end of receiver tube is flush with back of vehicle.

- 3) Install fasteners as shown above, and remove clamps.
- 4) Torque all 1/2" fasteners to 110 lb-ft.
- 5) Re-install spare tire and removed hardware if possible.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.