


**11352****NISSAN MAXIMA SEDAN AND ALTIMA SEDAN (INCLUDING HYBRID)****GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.**

\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\*




**WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.**

\*\* FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY\*\*

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1/2"	FISHWIRE TOOL
2	4	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER
3	4	1/2-13 x 1	CARRIAGE BOLT
4	4	HFN 1213	HEX FLANGE NUT



EXHAUST FLANGE NUTS



HITCH WEIGHT: 27 LBS.

**INSTALL TIME**

PROFESSIONAL: 45 MINUTES

NOVICE (DIY): 90 MINUTES

**INSTALL NOTES:**

- LOWER EXHAUST
- DRILLING REQUIRED
- FISHWIRE HARDWARE
- MAY REQUIRE PANEL REMOVAL

**INSTALLATION STEPS**

- 1) Remove the exhaust from vehicle:
    - A) Remove exhaust flange nuts (Fig A) and ground wire (if present) from muffler.
    - B) Pull each exhaust pipe/muffler assembly towards rear of car until the exhaust hanger has cleared the rubber isolator.
  - 2) Remove the heat shields by drilling out the rivets securing them to the frame rails. (Return the heat shields to the vehicle owner.)
- Note: If present remove, remove underbody panel on the spare tire well and reattach the bumper cover to the (2) metal tabs with the push button fasteners. Return panel to vehicle owner.
- 3) Enlarge the holes in the frame rails as shown above to allow the CM-SP6 spacer and carriage bolt to pass through.
  - 4) Fishwire a 1/2-13 carriage bolt and CM-SP6 spacer through the enlarged hole into the existing rearmost hole in each frame rail as shown.
  - 5) Reverse Pull Fishwire a 1/2-13 carriage bolt and CM-SP6 spacer into the enlarged hole in each frame rail as shown.
  - 6) Raise the hitch into position over the fishwired hardware and secure with 1/2" flange nuts as shown.
  - 7) Torque all hardware to 110 lb.-ft.
  - 8) Reinstall exhaust removed in Step 1.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.



The **FIRST** Name  
in Towing Products™

Trailer Hitches