



Safety glasses should be worn at all times while installing this product.

YEARS: 2015

MAKE: CHRYSLER

MODEL: 200

STYLE: SEDAN

WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY

WEIGHT CARRYING:
 TRAILER WEIGHT: 2,000 LBS.
 TONGUE WEIGHT: 200 LBS.

PRO INSTALL TIME: 40 MIN.
NOVICE INSTALL TIME: 80 MIN.

IF YOU ARE HESITANT TO UNDERTAKE THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED CURT INSTALLER FOR ADDITIONAL ASSISTANCE.

INSTALLATION REQUIRES:


	7mm 8mm 10mm 13mm SOCKET	3/4" SOCKET
	6" SOCKET EXTENSION	SCREW DRIVER
	DRILL BIT 3/16"	RIVET GUN

INSTALLATION TIPS:

- BEFORE YOU BEGIN INSTALLATION, READ ALL INSTRUCTIONS THOROUGHLY.
- TO EASE INSTALLATION, 2 PEOPLE MAY BE REQUIRED.
- USING PROPER TOOLS WILL GREATLY IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.

LEVEL OF DIFFICULTY: MODERATE


EASY	MODERATE	CHALLENGING
	TEMPORARY PART REMOVAL	
	LOWER EXHAUST FOR EASE OF INSTALL	
	RIVET REMOVAL	
	FISHWIRING REQUIRED	



INSTALLATION WALKTHROUGH:

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	HFN 1213, GR8	HEX FLANGE NUT
2	4	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER
3	4	1/2-13 x 1 1/2, GR8	CARRIAGE BOLT
4	4	1_2 FISHWIRE	1/2" FISHWIRE
5	4	11102628	3/16" RIVET

FISHWIRE TECHNIQUE
 INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND CUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL FISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOGS OF BOLT / SPACER INSIDE FRAME RAIL.
NOTE: SOME VEHICLES MAY REQUIRE FISHWIRE THROUGH END OF FRAME



1.) Remove corner plastic shield from each side of the vehicle by using an 8mm socket to remove 3 bolts and a phillips screwdriver to remove 1 nut (each side).

Set panels aside for reassembly.



2.) Note: Exhaust may need to be lowered for ease of exhaust tip removal, but must be reinstalled before hitch attachment.

To lower exhaust, remove isolator brackets from frame rails (2 brackets each side). Use a 13mm socket to remove 4 bolts (each side) holding the brackets to the frame.



INSTALLATION WALKTHROUGH:

3.) Remove exhaust tips by drilling out 1 rivet with a 3/16" drill bit (each side). Remove 3 bolts that secure the tips from each side with a 7mm socket.

Set exhaust tips aside for reassembly.



4.) Remove plastic fascia by drilling out rivets with a 3/16" drill bit (each side). Remove 3 bolts from center fascia with a 10mm socket. Unclip fascia around exhaust outlets and gently pull fascia away from the vehicle.

Set fascia aside for reassembly.



5.) If lowered, raise exhaust and secure back into position.

Remove square plug from frame access hole (both sides). Remove tape covering the rear outboard mounting holes. Fishwire 1/2" hardware through access holes and out mounting holes (2 places each side).



6.) Raise hitch into position and secure with 1/2" flange nuts. Note: Seam foam may need to be trimmed for proper mounting hole alignment.

Torque all 1/2" hardware to 110 ft-lbs.
Square plugs can be reinserted into frame access holes.



INSTALLATION WALKTHROUGH:

7.) Reinstall 2 exhaust tips, plastic fascia, and 2 plastic shields using original vehicle hardware and provided rivets.




Installation Complete



TOWING SAFETY INFORMATION


Gross Trailer Weight / GTW

The Gross Trailer Weight is the weight of the trailer & cargo. Measure this by putting the fully loaded trailer on a vehicle scale.



Tongue Weight / TW

The downward force that is exerted on the hitch ball by the coupler. The tongue weight will vary depending on where the load is positioned in relationship to the trailer axle(s). To measure the tongue weight, use either a commercial scale or a bathroom scale with the coupler at towing height. When using a bathroom scale with heavier tongue weights, use the method shown and multiply the scale reading by 3.



Weight Carrying / WC

The total weight of both the trailer and the cargo inside. Never exceed the weight capacity of your trailer hitch.

Weight Distribution / WD

Used to balance the weight of the cargo between the front and rear wheels throughout the trailer, allowing for better steering, braking, and level riding.



Sway Control

A device used to reduce the lateral movements of the trailer that are caused by the wind. This works in conjunction with a weight distribution hitch. Do not use this on a class 1 or 2 hitch, or with surge brakes.

How Much Can You Safely Tow?


TONGUE WEIGHT lbs	1000	2000	3000	4000	5000	6000	7000	8000	10,000	12,000
Tongue weight should be about 10 to 15 percent of the gross trailer weight.										
CLASS 1										
CLASS 2										
CLASS 3										
CLASS 4										
CLASS 5										
Camper	11'	12'	13'	14'	15'	16'				
lbs	1100	1200	1300	1400	1500	1600				
Vacation	14'	16'	18'	20'	22'	24'	26'	28'	30'	32'
lbs	2100	2400	2700	3000	3300	3600	3900	4200	4500	4800
Vacation	14'	16'	18'	20'	22'	24'	26'	28'	30'	32'
lbs	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
5th Wheel										

Refer to owner's manual for towing capabilities and limitations.

Ball Mount

The ball mount is placed inside the opening of the receiver hitch which is mounted to the vehicle. Make sure a hitch pin and clip is properly securing the ball mount to the receiver hitch before you begin towing.


- A: Rise. B: Drop. C: Hole Size. D: Length.



Trailer Ball

The connection from the hitch to the trailer. There are many factors that determine the correct hitch ball:

- Number one is the hitch ball's gross trailer weight rating.
- The mounting platform must be at least 3/8" thick.
- The hole diameter must not be more than 1/16" larger than the threaded shank.
- Every time you tow, check the nut and lock washer to make sure they are fastened securely.
- A: Ball Dia. B: Shank Dia. C: Shank Length. D: Shank Rise.



Coupler

The component that is placed over the trailer ball to connect the vehicle to the trailer. Be sure that the coupler size matches the size of the hitch ball and that the coupler handle is securely fastened. To determine what size hitch ball you need for your application you will need to know the size of coupler that is on the trailer. Be sure your coupler is properly adjusted to the ball you are using.

NOTE: For added security the use of safety devices such as Coupler Safety Pins and Locks is strongly recommended.

Safety Chains

Safety chains are a requirement and should be crossed under the tongue of the trailer so that the tongue will not drop to the road if it becomes separated from the hitch. Always leave enough slack so you can turn. Never allow the safety chains to drag on the ground and never attach the chains to the bumper.

Trailer Classification: Safety Chain Breaking Force - Minimum


- Class 1: 2,000 lbs. (8.9 kN)
- Class 2: 3,500 lbs. (15.6 kN)
- Class 3: 5,000 lbs. (22.2 kN)

The strength rating of each length of safety chain or its equivalent and its attachments shall be equal to or exceed in minimum breaking force the GVWR (Gross Vehicle Weight Rating) of the trailer.

Electrical

Trailer lights, Electric Brakes, Break-away systems - Every time you tow, be sure to check that all components are working properly.

Wiring identification by color:



GREEN YELLOW BROWN WHITE RED BLUE PURPLE

11403

CHRYSLER 200

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.


DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	HFN 1213, GR8	HEX FLANGE NUT
2	4	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER
3	4	1/2-13 x 1 1/2, GR8	CARRIAGE BOLT
4	4	1_2 FISHWIRE	1/2" FISHWIRE
5	4	11102628	3/16" RIVET

TOOLS REQUIRED	
7mm, 8mm, 10mm, 13mm	SOCKETS
3/4"	SOCKET
	RATCHET
6"	SOCKET EXTENSION
	SCREWDRIVER
	POWER DRILL
3/16"	DRILL BIT
	RIVET GUN
	TORQUE WRENCH



HITCH WEIGHT: 32 LBS.

INSTALL TIME

PROFESSIONAL: 40 MINUTES

NOVICE (DIY): 80 MINUTES



INSTALL NOTES:

- TEMPORARY PART REMOVAL
- LOWER EXHAUST
- RIVET REMOVAL
- FISHWIRING REQUIRED

DESIGNED FOR USE WITH BALLMOUNT #45521

DESIGNED FOR USE WITH EURO BALLMOUNT #45571 (1 7/8" BALL) AND #45572 (2" BALL)

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.



INSTALLED HITCH POSITION

INSTALLATION STEPS

1.) Remove corner plastic shield from each side of the vehicle by using an 8mm socket to remove 3 bolts, and a phillips screwdriver to remove 1 nut (each side).

2.) Note: Exhaust may need to be lowered for ease of exhaust tip removal, but must be reinstalled before hitch attachment.

To lower exhaust, remove isolator brackets from frame rails (2 brackets each side). Use a 13mm socket to remove 4 bolts (each side) holding the brackets to the frame.

3.) Remove exhaust tips by drilling out 1 rivet with a 3/16" drill bit (each side). Remove 3 bolts that secure the tips from each side with a 7mm socket.

Set exhaust tips aside for reassembly.

4.) Remove plastic fascia by drilling out rivets with a 3/16" drill bit (each side). Remove 3 bolts from center fascia with a 10mm socket. Unclip fascia around exhaust outlets and gently pull fascia away from the vehicle.

Set fascia aside for reassembly.

5.) If lowered, raise exhaust and secure back into position.

Remove square plug from frame access hole (both sides). Remove tape covering the rear outboard mounting holes. Fishwire 1/2" hardware through access holes and out mounting holes (2 places each side).

6.) Raise hitch into position and secure with 1/2" flange nuts.

Note: Seam foam may need to be trimmed for proper mounting hole alignment.

Torque all 1/2" hardware to 110 ft-lbs.

Square plugs can be reinserted into frame access holes.

7.) Reinstall 2 exhaust tips, plastic fascia and 2 plastic shields using original hardware and provided rivets.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.