

56185 NISSAN VERSA SEDAN

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Access the vehicle's wiring harness connectors behind the taillight housing in positions P1 and P2 as shown in the Wiring Location Guide.
2. Locate the vehicle's battery on the driver's side under the hood and disconnect the negative battery terminal.
3. Open the trunk. Remove all trunk floor coverings (A). Remove the two plastic push fasteners and the two 10mm screws on the rear scuff panel (B). Remove the rear scuff panel by pulling out on the bottom and then up.
4. Starting on driver's side of the trunk remove the plastic push fasteners holding the felt trunk liner in place (C). Pull out on the trunk liner so that the taillight wiring harness is exposed.
5. Remove the two 10mm nuts that hold the taillight housing in place (D). Remove taillight housing to locate the vehicle's taillight wiring harness connectors. The connectors will be similar to those on the T-Connector harness. Separate the connector from the taillight housing taking care not to damage the locking tabs.
6. Remove the grommet that the taillight wiring harness passes through from the vehicle. Make a cut in the grommet from the middle outwards that is large enough to pass the T-Connector's housings through (E). Route the T-Connector end with the yellow wire from inside the vehicle through the grommet's hole. Pass the housings through the grommet and reinstall the grommet back into the vehicle.
7. Insert the T-Connector end with the yellow wire between the separated housings. Make sure the housings are fully inserted with locking tabs in place.

Warning!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.


8. Inside the vehicle, locate a flat spot and adhere the black converter box using the double-sided tape provided.
9. Locate a suitable grounding point near the converter box such as an existing screw with nut in the vehicle's frame or drill a 3/32" pilot hole for the provided screw. Clean the ground area from any rust, dirt or paint. Secure the white ground wire using the ring terminal and screw provided.
10. Route the T-Connector end with the green wire to the passenger side behind the trunk liner and the removed scuff panel. Repeat Steps 4 through 7 on the passenger side using the T-Connector end with the green wire. Use the provide cable ties to secure any loose wires.
11. Route the 4-flat out from under the felt trunk liner to the center of the vehicle when in use. Roll up and store in an out of the way location when not in use.
12. Reinstall all items removed during install.
13. Reconnect the negative battery terminal.


IMPORTANT:

Exceeding the product's load rating can cause loss of warranty, overheating and potentially fire. Do not exceed the tow vehicle's lamp load rating or the product rating, whichever is lower:

Signal Circuits: 3.0 Amps
Tail/Running Light Circuits: 7.5 Amps

Check the vehicle owner's manual or contact the vehicle's manufacturer for more information.





Find more CURT products on our website.

Learn more about trailer hitches and towing we have.