

56197

CHEVROLET CAMARO WITHOUT LED TAILLIGHTS

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Access the vehicle's wiring harness connectors at positions P1 and P2 as shown in the Wiring Location Guide.
2. Locate the vehicle's battery and disconnect the negative battery terminal.
3. Open the trunk and remove the floor coverings. On both sides remove the plastic cover on top of the rear taillights by removing three plastic fasteners on each (A). Remove the vehicle's rear scuff panel by removing three plastic wing nuts on each side (B). Pull back on the felt trunk liner to reveal the rubber grommet leading to the back of the taillights (C).
4. On the driver's side remove the rubber grommet that the taillight wire harness passes through from the vehicle. Make a cut in the grommet from the center outwards that is large enough to pass the T-Connector's housings through.
5. Route the T-Connector end with the yellow wire through the grommet opening to the backside of the taillight (D).
6. Locate the taillight wiring harness. The harness will have connectors similar to those on the T-Connector harness (E). Separate the connectors taking care not to damage the alignment tabs (F).
7. Insert the T-Connector end with the yellow wire between the separated housings. Make sure the housings are fully inserted with locking tabs in place.
8. Re-seat rubber grommet.
9. Route the T-Connector end with the green wire to the passenger side behind the removed scuff panel.

10. Repeat Steps 3 through 8 on the passenger side using the T-Connector end with the green wire. Use the cable ties provided to secure wires to an existing wiring harness.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

11. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" pilot hole for the provided screw. Clean the ground area of rust and dirt. Secure the white ground wire using the ring terminal and screw provided.


12. Reinstall all items removed during install.

13. Route the 4-flat out from under the felt trunk liner and to the center of the vehicle when in use. Roll up and store in an out of the way location when not in use.

IMPORTANT:

Exceeding the vehicle's tow rating can cause loss of warranty, overheating and potential fire. Do not exceed the of tow vehicle's lamp load rating.

Check vehicle owner's manual or contact vehicle manufacturer for more information.





Find more CURT products on our website.

Learn more about trailer hitches and towing we have.