


# INSTALLATION INSTRUCTIONS

DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE'S LAMP LOAD RATING, WHICHEVER IS LOWER

## 56231 T-CONNECTOR KIT



## WIRING LOCATION GUIDE

### PASSENGER CARS (P)

Representative vehicle shown below

**P3** - Behind driver's side taillight housing, inside of trunk

**P4** - Behind passenger's side taillight housing, inside of trunk



## NOTE

All steps must be followed to ensure the T-connector will function properly. Once installed, test the function by connecting a test light or properly wired trailer.

## TOOLS NEEDED

Panel puller  
Small, flat blade screwdriver

## APPLICATIONS

Make	Model
Acura	TL

## WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle's lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 7.5 amps total

# INSTALLATION

## Step 1

Access the vehicle's wiring harness connectors inside the trunk behind the taillight in positions P3 and P4 as shown in the 'Wiring Location Guide'.

## Step 2

Locate vehicle's battery on the driver's side under the hood and disconnect the negative battery terminal (A).

## Step 3

Open the vehicle's tailgate. Remove all trunk floor coverings (B).

## Step 4

Remove the fasteners securing the rear scuff panel. Remove the scuff panel by pulling out on the bottom and then up (C).

## Step 5

On both sides of the trunk, remove the push fasteners and the screw-in fasteners securing the felt liner (D,E).

## Step 6

Starting on the driver's side, pull back on the felt liner to locate the vehicle's taillight wiring harness connectors (F). The connectors will be similar to those on the T-connector harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (G).

## Step 7

Insert the T-connector end with yellow wire between the separated two-pin connectors. Insert the T-connector end with brown wire between the separated three-pin connectors. Make sure the connectors are fully inserted with locking tabs in place (H).

**WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 8

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 9

Route the T-connector end with the green wire to the passenger side behind the removed scuff panel. Repeat Steps 6-7 on the passenger side using the T-connector end with the green wire.

## Step 10

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the double-sided tape provided (I).

## Step 11

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

## Step 12

Reinstall all items removed during install.  
Reconnect negative battery terminal.

