





## Knock Down Cargo Carrier Operation Manual & Safety Instruction Model: 18145



- Do not exceed maximum weight capacity of 500lbs.
- Distribute weight evenly on platform.
- This carrier is not intended for transporting humans.
- Do not carry loads wider or deeper than carrier.
- Do not carry flammable items on carrier.
- Do not allow exhaust fumes to blow directly on items. This is a FIRE HAZARD.
- CURT Manufacturing is not responsible for any damage if warnings are not heeded.

**Parts List:**

Item No.	Q'TY	Description
(1)	18	M6 locking-nut
(2)	18	M6 flat washer
(3)	6	V Support bracket
(4)	2	Carrier platform
(5)	4	M10 locking-nut
(6)	4	M10 spring washer
(7)	4	M10*1.5 flat washer
(8)	8	M8*35 hexagonal bolt
(9)	1	Receiver Bar
(10)	4	M10*60 hexagonal bolt
(11)	18	M6*35 hexagonal bolt
(12)	2	Upper U tube
(13)	8	M8 locking nut
(14)	8	M8 flat washer
(15)	2	Connection profile
(16)	1	M 4.5 split pin
(17)	1	1/2"-13 hex bolt
(18)	1	1/2" flat washer
(19)	1	1/2" Star washer
(20)	1	1/4"-20*1/2" hex bolt
(21)	1	nylon adaptor

**Assembly:**

1. Assemble V support bracket (3) on carrier platform (4) and upper U tube (12). secure with M6\*35 hexagonal bolts and M6 flat washer (1 and 2).

2. Align all the holes on assembled platforms (step 1) and receiver bar (9).Secure with M10\*60 (10) hexagonal bolts. Lock the receiver bar (9) with connection profile (15), then assemble upper U tube into connection profile, and secure with M8\*35 hexagonal bolts, M8 flat washer (13) and M8 locking nut (14). (Note: the connection profile with reflective tapes should be assembled outside, and the one without tapes should be located on the receiver bar side.)

3. Lock M10\*60 hexagonal bolt with M10 flat washer, M10 spring washer and M10 locking nut (7, 6 and 5 )

4. Put the nylon adaptor (21) onto the receiver bar (9), align all the holes and secure with 1/4"-20\*1/2" hex bolt. Insert carrier shank into vehicle receiver tube. Secure with anti-sway bolt & clip (16, 17, 18, 19). Ensure all hardware is tightly fastened.