

T-Connector Wiring Kit

INSTALLATION INSTRUCTIONS

1. Read instructions thoroughly before beginning.

2. Open the rear doors of the vehicle and temporarily remove the interior trim panes on each side of the vehicle near the rear doors, expose the tail light wiring access ports (fig. 1A) and the threshold trim plate along the floor across the door opening (fig. 1B).



Fig 1

2. Locate the vehicle's tail light wiring harness on each side of the van behind the tail lights. The harness will have connectors similar in appearance to those on the T-Connector harness.

3. Beginning with the left (driver's) side, disconnect the vehicle harness connectors. Check the connectors for dirt and debris and clean if necessary, taking care not to damage the locking tabs.

4. Position the T-Connector ends with the yellow wire between the separated vehicle connectors. Firmly press the connector ends together until the locking tabs engage. Take care not to damage the locking tabs.

5. Route the T-Connector ends with the Green wire out from under the trim panel, along the threshold to the right (passenger) side of the vehicle.

6. Repeat steps 3 & 4 for the left (passenger) side using the T-Connector ends with the green wire.

7. Find a clean area near the wiring harness to attach the ground screw. Clear away any dust or debris and drill a 3/32" hole.

Caution: Do not drill into any exposed surfaces or through the vehicle body.

Attach the T-Connectors white wire with the ring terminal to the vehicle using the #10 screw provided.

8. Confirm correct operation with a test light or by using a trailer.




#55338

T-Connector Wiring Kit

INSTALLATION INSTRUCTIONS

Fits: 1987-96 Chevrolet Full Size Vans (2 Way Systems)

1987-96 GMC Full Size Vans (2 Way Systems)



Kit Includes:

- (1) Wiring Harness with 4 Pin Connector
- (2) 6" Cable Ties
- (1) #10 Self Tapping Ground Screw

© 2003 Electrical Components, Inc.

Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.