

55345

FORD EXPLORER
FORD EXPLORER (4-DR.)
MERCURY MOUNTAINEER

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the tailgate and remove both taillight assemblies by removing the two phillips head screws. [A]

2. Starting on the drivers side separate the top two connectors from the back of the taillight housing making sure not to break the locking tabs. [B] Insert the T-connector end with the yellow wire in-between the top separated connector and insert the T-connector end with the brown wire in-between the other separated connector. [C]

3. Route the T-connector end with the green wire and the 4-flat wire down through the opening under the drivers side taillight. [D] Route the green wire across the backside of the bumper and up through the opening on the passenger side. Repeat step 2 on the passenger side only separating the top connector using the green wire. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included. Reassemble the taillights.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location.

WARNING!
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

