55355 **CHEVROLET VENTURE OLDSMOBILE SILHOUETTE PONTIAC MONTANA** PONTIAC TRANS SPORT VAN

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

- 1. Open the vehicle's hatch, and temporarily remove the driver's side storage compartment door (A).
- 2. Remove the four plastic trim fasteners securing the storage compartment panel. To locate the vehicle's wiring harness, pull back the side trim panel to reveal a housing similar to the housing on the end of the T-Connector. It will be towards the rear of the opening (B).
- 3. Clean if the housing if necessary. Attach the T-Connector to the vehicle's wiring harness. Make sure that the connector is fully inserted with locking tabs in place.

Note:

Depending on vehicle options, the connector may already be connected with another. If so, seperate the housings, taking care not to damage the locking tabs. Insert the T-Connector between the seperated housings, making sure that the connector is fully inserted with locking tabs in place.

- 4. Locate a suitable grounding point near the adapter. Clean dirt and rust proofing from the area. Drill a 3/32" hole and secure the white wire using the eyelet and screw provided.
- 5. Test the installation with a test light or trailer. All connections must be complete for the T-Connector to function properly. Secure the black box to the vehicle using the screw or cable tie provided.
- 6. Reinstall the storage compartment panel using the plastic trim fasteners removed in Step 1. Replacement fasteners are provided should damage occur. Retain the 4-flat connector in the storage compartment tray. for future use. Return the storage compartment door to its original position.







55355

WARNING! Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.