

# 55378

TOYOTA TUNDRA

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the hood of the vehicle and remove the vehicles negative battery cable also remove the bracket holding the battery in place. Temporarily reposition the battery slightly towards the engine.

2. Locate the gray plastic connector in-between the battery and the drivers side fender. [A] Remove the protective cap and insert the harness connector attached to the fuse holder into the vehicles connector. Make sure the connectors are fully inserted with locking tabs in place.

3. Route the other end of the harness to the positive side of the battery. Attach the ring terminal to the positive side of the battery. Reposition the battery to its original location. Secure any loose wires using cable ties provided. Install the 10 amp fuse into the fuse holder.

4. Locate the vehicles factory tow plug it will be located behind the rear bumper along the passenger side frame rail Location (T3). [B] Remove the protective cap being sure not to damage the locking tabs. Insert the harness connector into the vehicles connector. Make sure the connectors are fully inserted with locking tabs in place.

5. Adhere the black converter box to the bottom side of the bumper support in a secure out of the way location find a flat clean surface that is out of the path of spray and debris from the rear wheels and road of the vehicle using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

