

# 55379

TOYOTA TACOMA  
TOYOTA PICKUP

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Remove both taillight assemblies by removing 4 phillips screws holding each assembly in place. **A** Pull out on the taillight assemblies being sure not to damage the alignment tabs. **B** Behind the taillights locate the vehicles taillight wiring harness. The harness will have connectors similar to those on the T-connector harness. Separate the connectors being sure not to damage the locking tabs. **C**

2. Starting on the drivers side route the T-connector end with the yellow wire up through the opening under the taillight assembly and insert in-between the separated connectors. **D** Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-connector end with the green wire across the backside of the bumper to the passenger side and up through the opening under the passenger side taillight. Repeat step 2 on the passenger side using the green wire.


4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.


5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.





55379