

56009

JEEP GRAND CHEROKEE

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer

1. Open the rear hatch. Using a screwdriver, remove the two plastic fasteners securing each taillight housing (A). Remove the taillight housings by pulling out on the taillights taking care not to damage the alignment tabs (B).

2. Starting on the driver's side separate the vehicle's taillight wiring harness from the back of the taillight taking care not to damage the alignment tabs (C). Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.


3. Route the T-Connector end with the green wire down through the opening under the taillight assembly (D). Route the T-Connector end with the green wire under the vehicle along the backside of the bumper to the passenger side and up to the passenger side taillight housing through the opening on the passenger side. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.


WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.





56009