

56036

SATURN ION

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and remove the taillight assemblies by removing the T15 Torx screws holding them in place. [A] [B] Pull out on the taillight assembly make sure not to damage the alignment tabs.

2. Starting on the passenger side locate the vehicles taillight wiring harness connectors. The connectors will be similar to those on the T-connector. [C] Separate the connectors being sure not to damage the locking tabs. Route the T-connector end with the green wire up from underneath the vehicle and through the opening under the taillight. Insert the T-connector end with the green wire in-between the separated connectors on the passenger side make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-connector end with the yellow wire along the back side of the bumper to the drivers side and up through the opening under the taillight. Repeat step 2 on the drivers side using the yellow wire.

4. Adhere the black converter box to the frame of the car using the double-sided tape provided.

5. Adhere the black converter box to the bottom side of the bumper support in a secure out of the way location find a flat clean surface that is out of the path of spray and debris from the rear wheels and road of the vehicle using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

