

56046

CHEVROLET IMPALA

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and remove the rear scuff panel by removing one plastic fastener and one plastic wing nut on each side holding it in place. [A] On the passenger side pull back on the felt trunk liner to reveal three plastic wing nuts holding the taillight in place. [B] Remove plastic wing nuts and pull passenger side taillight away from the vehicle being sure not to damage the alignment tabs. [C]

2. Under the passenger side taillight assembly locate the vehicles factory tow harness. [C] The harness will have connectors similar to those on T-connector harness. Separate the vehicles connectors being sure not to damage the locking tabs. [D] Insert the T-connector end in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place. [E]

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

4. Remove the grommet behind the taillight housing and make a small slit from the outside of the grommet to the center. Route the 4-flat wire through the grommet to the inside of the trunk and re-seat the grommet. [F] Route the 4-flat out from under the felt trunk liner into the trunk compartment. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

