

56048

FORD FUSION

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and partially remove floor coverings. [A] Remove the rear scuff panel by removing the plastic fasteners holding it in place and pulling up. [B][C]
 2. On the drivers side pull back on the felt trunk liner. Behind the trunk liner locate the vehicles taillight wiring harness. [D] The harness connectors will be similar to those on the T-connector harness. Separate the connectors being sure not to damage the locking tabs. [E] Insert the T-connector end with the yellow wire in-between the separated connectors. [E] Make sure the connectors are fully inserted with locking tabs in place.
- WARNING!**
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.
3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.
 4. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included. Route the black wire through any rubber grommet in the trunk area if applicable to the black converter.
 5. Adhere the black converter box to the frame of the car using the double-sided tape provided. [F] Secure any loose parts of the T-connector with the cable ties provided.
 6. Route the T-connector end with the green wire to the passenger side behind the removed rear scuff panel. Repeat Step 2 on the passenger side using the green wire.
 7. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.



