

56082

MAZDA MX-5 MIATA

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and remove the floor cover, the trim panels on the drivers and passengers side, and the rear scuff panel by removing several plastic fasteners using a trim puller. [A][B][C][D] Remove jack storage cover. [E]

2. Starting on the passenger side pull back on the rear trim panel to reveal the vehicles taillight wiring harness it will have connectors similar to those on the T-connector. [F] Separate the connectors being sure not to damage the locking tabs. Insert the T-connector ends with the red and green wires in between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place. [G]

3. Route the T-connector end with the yellow wire out from behind the trim panel across the remove scuff panel to the passenger side. Repeat step 2 on the passenger side using the yellow wire.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. [G] Secure any loose parts of the T-connector with the cable ties provided.

6. Route the 4-flat wire out of the jack storage compartment to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the jack storage compartment. [H]

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

