

56095

LINCOLN MKT

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the rear hatch. Remove both taillight housings by removing screws on each using a 8mm socket. [A] Pull out on the housing to locate the vehicles taillight wiring harness. [B] The harness will have connectors similar to those on the T-connector harness.

2. Starting on the drivers side separate the connectors being sure not to damage the locking tabs. [C] Insert the T-connector end with the yellow wire in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place. [D]

3. Route the T-connector end with the green wire and the 4-flat down through the opening under the taillight. [E][F] Under the vehicle route the green wire across the backside of the bumper to the passenger side and up through the opening under the passenger side taillight. Repeat step 2 on the passenger side using the green wire.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.





5. Adhere the black converter box to the frame of the car using the double-sided tape provided. [E]

6. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included.

7. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.





56095