

56114


FORD FIESTA SEDAN

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Open the trunk (A) and remove the spare tire compartment cover (B). Remove the rear scuff panel by removing three plastic fasteners holding it in place (C) and pulling up. On both sides of the trunk pull back on the felt trunk liner behind the taillights to locate the vehicles taillight wiring harness (D). The harness will have connectors similar to those on the T-connector.


2. On the driver side separate the connectors being sure not to damage the locking tabs (E). Insert the T-Connector end with the yellow wire between the connectors (F). Make sure the connectors are fully inserted with locking tabs in place.

3. Route the green wire to the passenger side behind the scuff panel. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.

WARNING!
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using eyelet and screw provided.

5. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.



56114