
## 56147 TOYOTA PRIUS

## WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

- 1. Open the trunk. Remove all trunk floor covers (A) and trays (B). Remove the rear scuff panel by pulling out on the bottom and up on the top (B). Remove the battery cover on the passenger side (C).
- 2. On the passenger's side pull back on the felt trunk liner to locate the vehicle's taillight wiring harness connectors (D). The connectors will be similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs. Insert the T-Connector end with the green wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

## WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

- 3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure the eyelet of the white ground wire using the screw provided.
- 4. Locate a flat spot and adhere the black converter box to the frame of the vehicle using the double-sided tape provided.
- 5. Route the the T-Connector end with the yellow wire to the driver side behind the removed scuff panel. Repeat Step 2 on the passenger side using the T-Connector end with the yellow wire. Use the provided cable ties to secure any loose wires.
- 6. Route the black power wire to the battery's positive. Remove the battery's cover and remove the nut securing the red battery cable (E).

Place the fuse holder's ring terminal over the stud and replace the nut. Install the 10 amp fuse provided in the fuse holder and close the fuse holder's cap.

- 7. Reinstall all items removed during install.
- 8. Route the 4-flat out from under the felt trunk liner to the center of the vehicle when in use. Roll up and store in an out of the way location when not in use.



