

56153

HYUNDAI VELOSTER

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer

English


1. Open the rear hatch and remove both taillight assemblies by removing two phillips screws holding them in place (A). Pull out on taillight assembly taking care not to damage the alignment tabs.
2. Starting on the driver side locate the vehicle's taillight wiring harness connector (B). The connector will be similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs (C). Insert the T-Connector end with the yellow wire between the seperated connectors. Make sure the connectors are fully inserted with locking tabs in place.


WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.
5. Review the CME-PCL-INS instruction sheet and route the black power wire from the battery to the converter as shown.
6. Adhere the black converter box behind the removed taillight housing of the vehicle using the double-sided tape provided.

7. Route the 4-flat and the T-Connector end with the green wire down under the vehicle thru the opening under the taillight (D). Route the green wire across to the passenger side along the backside of the bumper and up through the opening under the passenger side taillight. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.
8. Route the 4-flat wire to the center of the vehicle. Secure the 4-flat to the center of the vehicle in a convenient out of the way location. Secure any loose wires with the cable ties provided.
9. Reinstall all items removed during install.





Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.