

# 56156 TOYOTA PRIUS V

## English

### WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



#### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

#### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

1. Open the Hatch. Remove all trunk floor covers and foam trays (A). On both sides of the rear cargo area remove the plastic cargo trays (B). Remove the rear scuff panel by removing three plastic fasteners and pulling up (C). On both sides of the cargo area remove the plastic cover covering the taillight wiring harness.

2. Behind the plastic cover locate the vehicle's taillight wiring harness connectors (D). The connectors will be similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs (E). On the passenger side insert the T-Connector end with the green wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

#### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure the eyelet of the white ground wire using the screw provided.

4. Locate a flat spot and adhere the black converter box to the inside body panel of the vehicle behind the felt trunk liner near the connector using the double-sided tape provided.

5. Route the T-Connector end with the yellow wire across to the driver side behind the removed scuff panel. Repeat Step 2 on the driver side using the T-Connector end with the yellow wire. Use the cable ties provided to secure wires to an existing wiring harness.

6. Route the black power wire to the battery's positive. Remove the battery's cover and remove the nut securing the red battery cable (F). Place the fuse holder's ring terminal over the stud and replace the nut. Install the 10 amp fuse provided in the fuse holder and close the fuse holder's cap.

7. Route the 4-flat out from under the felt trunk liner and to the center of the vehicle and out of the trunk when in use. Roll up and store in an out of the way location when not in use.

8. Reinstall all items removed during install.

